

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W.T. RYAN 1100 AGENCY GOODYEAR PD.
DATE 2-4-15 TIME 1049
INTOXILYZER SERIAL # 80-001858 LOCATION 1111 S LITCHFIELD RD GOODYEAR AZ

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0-100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0. 098 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W.T. RYAN 1100 W.T. Ryan

DPS Form Exh G-2 (Rev 05-01)

TAKEN OUT OF SERVICE FOR MAINT AT DPS

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST W-T. Ryan AGENCY GOODYEAR P.D.

DATE 2-4-15 TIME 1054

INTOXILYZER SERIAL # 80-001858 LOCATION 1111 S LUTHERED RD GOODYEAR AZ

() 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

() 1. Clock time check.

() 2. Date check.

OPERATIONAL TESTS

() 1. Alcohol-free subject test result 0. 000 AC.

() 2. Error recognition logic system functioning.

Not a Successfully Completed Test Sequence printed

() 3. Proper sample recognition system.

Not a Successfully Completed Test Sequence printed

Deficient sample printed.

() 4. Standard Calibration Check standard 0. 100 AC. Result 0. 099 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS

TAKEN OUT OF SERVICE FOR YEARLY MAINT AT DPS

SIGNATURE

W-T. Ryan 1100

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

02/04/2015

10:54:47

Standard Lot#: 25913100A2

Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100

GOODYEAR PD

Operator: W. RYAN #1100

GOODYEAR PD

Subject: TEST,TEST

DOB: 02/04/1959

Sex: M Weight: 180

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	10:56:08
Diagnostic Test	Pass	10:56:43
Air Blank	0.000	10:57:10
0.100 Cal Check	0.098	10:57:31
Air Blank	0.000	10:58:01
Subject Test	0.000	10:58:19
Air Blank	0.000	10:58:46
Wait	ABT*	
Air Blank	0.000	10:59:23

*Sequence Aborted

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: 1111 S LITCHFIELD RD
Serial Number: 80-001858
Core Version: 8105.48
02/04/2015 10:59:44

Standard Lot#: 25913100A2
Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100
GOODYEAR PD

Operator: W. RYAN #1100
GOODYEAR PD

Subject: TEST,TEST
DOB: 02/04/1959
Sex: M Weight: 180

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	IPS*	11:00:26
Air Blank	0.000	11:00:55

*Improper Sample

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: 1111 S LITCHFIELD RD
Serial Number: 80-001858
Core Version: 8105.48
02/04/2015 11:01:15

Standard Lot#: 25913100A2
Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100
GOODYEAR PD

Operator: W. RYAN #1100
GOODYEAR PD

Subject: TEST,TEST
DOB: 02/04/1959
Sex: M Weight: 180

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	RFI*	11:01:53
Air Blank	RFI*	11:02:03

*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

02/04/2015

11:02:39

Standard Lot#: 25913100A2

Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100

GOODYEAR PD

Operator: W. RYAN #1100

GOODYEAR PD

Subject: TEST,TEST

DOB: 02/04/1959

Sex: M Weight: 180

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	11:03:31
Diagnostic Test	Pass	11:04:06
Air Blank	0.000	11:04:33
0.100 Cal Check	0.098	11:04:54
Air Blank	0.000	11:05:24
Subject Test	0.045*	11:08:31
Air Blank	0.000	11:09:02
Air Blank	0.000	11:09:29
Subject Test	XXX**	11:09:50
Air Blank	0.000	11:10:23

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: 1111 S LITCHFIELD RD
Serial Number: 80-001858
Core Version: 8105.48
02/04/2015 11:11:25

Standard Lot#: 25913100A2
Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100
GOODYEAR PD

Operator: W. RYAN #1100
GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	11:11:57
0.100 Cal Check	0.099	11:12:17
Air Blank	0.000	11:12:47

Preventative Maintenance
Performed -- Timer Reset



ARIZONA DEPARTMENT OF PUBLIC SAFETY
INTOXILYZER MAINTENANCE REPORT

CR NO. I800018580003

Page 1 of 1

AGENCY Goodyear Police Department
Goodyear, AZ 85338
OFFICER RYAN, #1100
DATE February 06, 2015



INSTRUMENT

80001858

INSTRUMENT LOCATION

Goodyear Police Department

MAINTENANCE REQUESTED

Preventative Maintenance

MAINTENANCE PERFORMED

Preventative Maintenance Performed:

Inspection, Calibration, Verification

A handwritten signature in cursive script, appearing to read "Joseph M Slowinski".

JOSEPH M SLOWINSKI, #6101, Electronics Technician
Central Regional Crime Laboratory
2102 W. Encanto Blvd., Phoenix, AZ 85009
(602) 223-2394



ARIZONA DEPARTMENT OF PUBLIC SAFETY

INTOXILYZER MAINTENANCE REPORT

Page 1 of 1

AGENCY Goodyear Police Department
 Goodyear, AZ 85338
OFFICER RYAN, #1100
DATE February 19, 2015



INSTRUMENT

80001858

INSTRUMENT LOCATION

Goodyear Police Department

MAINTENANCE REQUESTED

Repair

MAINTENANCE PERFORMED

Parts Replaced:

Keyboard and Internal Keyboard Connection

A handwritten signature in black ink, appearing to read "Joseph M Slowinski".

JOSEPH M SLOWINSKI, #6101, Electronics Technician
Central Regional Crime Laboratory
2102 W. Encanto Blvd., Phoenix, AZ 85009
(602) 223-2394

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST W.T. RYAN #1100 AGENCY GOODYEAR P.D.

DATE 2-19-15 TIME 1429

INTOXILYZER SERIAL # 80-001858 LOCATION 1111 S LITCHFIELD RD GOODYEAR AZ

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

1. Clock time check.

2. Date check.

* OPERATIONAL TESTS

1. Alcohol-free subject test result 0. 000 AC.

2. Error recognition logic system functioning.

Not a Successfully Completed Test Sequence printed

3. Proper sample recognition system.

Not a Successfully Completed Test Sequence printed

Deficient sample printed.

4. Standard Calibration Check standard 0. 100 AC. Result 0 99 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS

BROUGHT BACK INTO SVC AFTER DPS MAINT.

SIGNATURE W.T. Ryan 1100

DPS Form Exh G-4 (Rev 05-01)

MISSED AIR BLANK SEQUENCE ABORTED

INTOXILYZER 8000
Location: 1111 S LITCHFIELD RD
Serial Number: 80-001858
Core Version: 8105.48
02/19/2015 14:29:12

Standard Lot#: 25913100A2
Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100
GOODYEAR PD

Operator: W. RYAN #1100
GOODYEAR PD

Subject: TEST,TEST
DOB: 02/19/1959
Sex: M Weight: 180

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	14:30:33
Diagnostic Test	Pass	14:31:08
Air Blank	0.000	14:31:35
0.100 Cal Check	0.100	14:31:56
Air Blank	0.000	14:32:26
Subject Test	0.000	14:32:53
Air Blank	0.000	14:33:20
Wait	ABT*	
Air Blank	0.000	14:34:01

*Sequence Aborted

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: 1111 S LITCHFIELD RD
Serial Number: 80-001858
Core Version: 8105.48
02/19/2015 14:34:28

Standard Lot#: 25913100A2
Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100
GOODYEAR PD

Operator: W. RYAN #1100
GOODYEAR PD

Subject: TEST,TEST
DOB: 02/19/1959
Sex: M Weight: 180

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	14:36:15
Diagnostic Test	Pass	14:36:50
Air Blank	0.000	14:37:17
0.100 Cal Check	0.099	14:37:38
Air Blank	ABT*	14:37:47
Air Blank	0.000	14:38:15

*Sequence Aborted

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: 1111 S LITCHFIELD RD
Serial Number: 80-001858
Core Version: 8105.48
02/19/2015 14:38:37

Standard Lot#: 25913100A2
Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100
GOODYEAR PD

Operator: W. RYAN #1100
GOODYEAR PD

Subject: TEST,TEST
DOB: 02/19/1959
Sex: M Weight: 180

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	IPS*	14:39:19
Air Blank	0.000	14:39:47

*Improper Sample

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: 1111 S LITCHFIELD RD
Serial Number: 80-001858
Core Version: 8105.48
02/19/2015 14:40:09

Standard Lot#: 25913100A2
Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100
GOODYEAR PD

Operator: W. RYAN #1100
GOODYEAR PD

Subject: TEST,TEST
DOB: 02/19/1959
Sex: M Weight: 180

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	RFI*	14:41:02
Air Blank	RFI*	14:41:11

*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: 1111 S LITCHFIELD RD
Serial Number: 80-001858
Core Version: 8105.48
02/19/2015 14:41:42

Standard Lot#: 25913100A2
Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100
GOODYEAR PD

Operator: W. RYAN #1100
GOODYEAR PD

Subject: TEST,TEST
DOB: 02/19/1959
Sex: M Weight: 180

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	14:42:54
Diagnostic Test	Pass	14:43:29
Air Blank	0.000	14:43:57
0.100 Cal Check	0.099	14:44:18
Air Blank	0.000	14:44:47
Subject Test	RFI*	14:47:44
Air Blank	0.000	14:48:17

*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: 1111 S LITCHFIELD RD
Serial Number: 80-001858
Core Version: 8105.48
02/19/2015 14:48:39

Standard Lot#: 25913100A2
Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100
GOODYEAR PD

Operator: W. RYAN #1100
GOODYEAR PD

Subject: TEST,TEST
DOB: 02/19/1959
Sex: M Weight: 180

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	14:49:43
Diagnostic Test	Pass	14:50:18
Air Blank	0.000	14:50:46
0.100 Cal Check	0.099	14:51:07
Air Blank	0.000	14:51:36
Subject Test	0.011*	14:54:44
Air Blank	0.000	14:55:11
Air Blank	0.000	14:55:39
Subject Test	XXX**	14:55:58
Air Blank	0.000	14:56:34

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W.T. RYAN #1100 AGENCY GOODYEAR P.D.

DATE 2-19-15 TIME 1423

INTOXILYZER SERIAL # 80-001858 LOCATION 1111 S LITCHFIELD RD GOODYEAR AZ

(S) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.106 AC.
OR

Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$

(S) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"

(S) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.

(S) 4. Air blank completed.

(S) 5. Calibration check completed. Test results 0.099 AC.

(S) 6. Air blank completed.

(S) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W.T. Ryan 1100

INTOXILYZER 8000
Location: 1111 S LITCHFIELD RD
Serial Number: 80-001858
Core Version: 8105.48
02/19/2015 14:23:54

Standard Lot#: 25913100A2
Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100
GOODYEAR PD

Operator: W. RYAN #1100
GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	14:24:31
0.100 Cal Check	0.099	14:24:52
Air Blank	0.000	14:25:21

Preventative Maintenance
Performed -- Timer Reset