EXHIBIT G-2 THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W. T. RYAN 1100 AGENCY GOODYGAR P.D
DATE 10-21-15 TIME 1049
INTOXILYZER SERIAL # 80 - 000312 LOCATION [111 S LITCHFIELD RS 6
1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution OR Pour a standard alcohol concentration solution AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C 1. Intoxilyzer 8000 display reads "PUSH BUTTON TO START" CONTACT QAS 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER. 4. Air blank completed. 5. Calibration check completed. Test results 0. LOO AC. 6. Air blank completed. 7. Remove printed record. Attach the record to the completed checklist.
SIGNATURE (U _) [O D DPS Form Exh G-2 (Rev 05-01)
NO PROBUMS 31 DAY TIME OUT
31 DAY TIME OUT

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-000312 Core Version: 8105.48

10/21/2015 10:49:43

Standard Lot#: 16014100A1

Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100

GOODYEAR PD

Operator: W. RYAN #1100

GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	10:50:15

0.100 Cal Check 0.100 10:50:35 Air Blank 0.000 10:51:06

Preventative Maintenance Performed -- Timer Reset