

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W.T. RYAN #1100 AGENCY GOODYEAR POLICE DEPT  
DATE 10-1-16 TIME 1528  
INTOXILYZER SERIAL # 80-001858 LOCATION 1113 LITCHFIELD RD GOODYEAR AZ

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0. 100 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W.T. Ryan 1100

INTOXILYZER 8000  
Location: 1111 S LITCHFIELD RD  
Serial Number: 80-001058  
Core Version: 8105.48  
10/01/2016

15:28:29

Standard Lot#: 26614100A6  
Last Changed By: W. RYAN #1100

OAS: W. RYAN #1100  
GOODYEAR PD

Operator: W. RYAN #1100  
GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	15:29:21
0.100 Cal Check	0.100	15:29:42
Air Blank	0.000	15:30:11

Preventative Maintenance  
Performed -- Timer Reset

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W.T. RYAN #1100 AGENCY GOODYEAR POLICE DEPT  
DATE 10-1-16 TIME 1538  
INTOXILYZER SERIAL # 80-001858 LOCATION 111 S LITCHFIELD RD GOODYEAR AZ

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0. 099 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W.T. Ryan #1100

PRINTER NO PAPER,  
REPRINTED

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

10/01/2016

15:39:49

-----  
Standard Lot#: 26614100A6

Last Changed By: W. RYAN #1100

-----  
QAS: W. RYAN #1100

GOODYEAR PD

-----  
Operator: W. RYAN #1100

GOODYEAR PD

-----  
Test                      g/210L                      Time  
-----  
Air Blank                      0.000                      15:39:29  
0.100 Cal Check              0.099                      15:39:50  
Air Blank                      0.000                      15:40:19

Preventative Maintenance

Performed -- Timer Reset

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W. T. RYAN #1100 AGENCY GOODYEAR POLICE DEPT

DATE 10-1-16 TIME 1537

INTOXILYZER SERIAL # 80-001858 LOCATION 1111 S LITCHFIELD RD GOODYEAR AZ

(H) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.  
OR

Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$

- (H) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (H) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (H) 4. Air blank completed.
- (H) 5. Calibration check completed. Test results 0.096 AC.
- (H) 6. Air blank completed.
- (H) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W. T. Ryan 1100

DPS Form Exh G-2 (Rev 05-01)

TESTED PRINTER, PRINTED OK

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

10/01/2016

15:37:04

-----  
Standard Lot#: 26614100A6

Last Changed By: W. RYAN #1100

-----  
QAS: W. RYAN #1100

GOODYEAR PD

-----  
Operator: W. RYAN #1100

GOODYEAR PD

-----  
Test                      g/210L                      Time  
-----  
Air Blank                      0.000                      15:37:34  
0.100 Cal Check                0.096                      15:37:55  
Air Blank                      0.000                      15:38:24

Preventative Maintenance  
Performed -- Timer Reset

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W.T. RYAN 1100 AGENCY GOODYEAR P.P.  
DATE 10-6-16 TIME 0339

INTOXILYZER SERIAL # 90-001858 LOCATION 1111 S LITCHFIELD RD GOODYEAR AZ

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- ( ) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START" CONTROL QAS
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0.098 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W.T. Ryan 1100

DPS Form Exh G-2 (Rev 05-01)

STANDARD CHANGE

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

10/06/2016

03:39:29

-----  
Standard Lot#: 28515100A1

Last Changed By: W. RYAN #1100

-----  
QAS: W. RYAN #1100

GOODYEAR PD

-----  
Operator: W. RYAN #1100

GOODYEAR PD

-----  
Test                      g/210L                      Time  
-----  
Air Blank                      0.000                      03:39:59  
0.100 Cal Check                0.098                      03:40:20  
Air Blank                      0.000                      03:40:50

Preventative Maintenance  
Performed -- Timer Reset

STANDARD CHANGE



EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W.T. RYAN 1100 AGENCY GOODYEAR P.P.

DATE 10-18-16 TIME 2329

INTOXILYZER SERIAL # 80-001858 LOCATION 1111 S LITCHFIELD RD GOODYEAR AZ

(✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100AC.  
OR

Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$

- (SS) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"  
(SS) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.  
(SS) 4. Air blank completed.  
(SS) 5. Calibration check completed. Test results 0. 099 AC.  
(SS) 6. Air blank completed.  
7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W.T. Ryan #1100

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

10/18/2016

23:29:00

-----  
Standard Lot#: 28515100A1

Last Changed By: W. RYAN #1100

-----  
QAS: W. RYAN #1100

GOODYEAR PD

-----  
Operator: W. RYAN #1100

GOODYEAR PD  
-----

Test	g/210L	Time
Air Blank	0.000	23:29:33
0.100 Cal Check	0.099	23:29:54
Air Blank	0.000	23:30:24

Preventative Maintenance  
Performed - Timer Reset

EXHIBIT G-4

THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST W.T. RYAN #1100 AGENCY GOODYEAR P.D.

DATE 10-18-16 TIME 2332

INTOXILYZER SERIAL # 80-001858 LOCATION 1111 S LITCHFIELD RD GOODYEAR AZ

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

1. Clock time check.  
 2. Date check.

OPERATIONAL TESTS

1. Alcohol-free subject test result 0. 000 AC.  
 2. Error recognition logic system functioning.  
Not a Successfully Completed Test Sequence printed  
 3. Proper sample recognition system.  
Not a Successfully Completed Test Sequence printed  
Deficient sample printed.  
 4. Standard Calibration Check standard 0. 100 AC. Result 0. 098 AC.

Instrument is operating properly and accurately. YES  NO

COMMENTS

NO PROBLEMS

SIGNATURE W.T. Ryan 1100

INTOXILYZER 8000  
Location: 1111 S LITCHFIELD RD  
Serial Number: 80-001858  
Core Version: 8105.48  
10/18/2016 23:32:18

---

Standard Lot#: 28515100A1  
Last Changed By: W. RYAN #1100

---

QAS: W. RYAN #1100  
GOODYEAR PD

---

Operator: W. RYAN #1100  
GOODYEAR PD

---

Subject: TEST,TEST  
DOB: 10/18/1959  
Sex: M Weight: 180

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	23:33:26
Diagnostic Test	Pass	23:34:01
Air Blank	0.000	23:34:28
0.100 Cal Check	0.099	23:34:49
Air Blank	0.000	23:35:18
Subject Test	0.000	23:35:33
Air Blank	0.000	23:36:00
Wait	ABT*	
Air Blank	0.000	23:36:39

\*Sequence Aborted

Not a Successfully Completed Test Sequence

INTOXILYZER 8000  
Location: 1111 S LITCHFIELD RD  
Serial Number: 80-001858  
Core Version: 8105.48  
10/18/2016 23:37:07

---

Standard Lot#: 28515100A1  
Last Changed By: W. RYAN #1100

---

QAS: W. RYAN #1100  
GOODYEAR PD

---

Operator: W. RYAN #1100  
GOODYEAR PD

---

Subject: TEST,TEST  
DOB: 10/18/1959  
Sex: M Weight: 180

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	IPS*	23:37:50
Air Blank	RFI**	23:38:12

\*Improper Sample

\*\*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

10/18/2016

23:38:39

---

Standard Lot#: 28515100A1

Last Changed By: W. RYAN #1100

---

QAS: W. RYAN #1100

GOODYEAR PD

---

Operator: W. RYAN #1100

GOODYEAR PD

---

Subject: TEST,TEST

DOB: 10/18/1959

Sex: M Weight: 180

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	RFI*	23:39:20
Air Blank	0.000	23:39:49

\*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000  
Location: 1111 S LITCHFIELD RD  
Serial Number: 80-001858  
Core Version: 8105.48  
10/18/2016 23:40:18

---

Standard Lot#: 28515100A1  
Last Changed By: W. RYAN #1100

---

QAS: W. RYAN #1100  
GOODYEAR PD

---

Operator: W. RYAN #1100  
GOODYEAR PD

---

Subject: TEST,TEST  
DOB: 10/18/1959  
Sex: M Weight: 180

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	23:41:25
Diagnostic Test	Pass	23:42:00
Air Blank	0.000	23:42:28
0.100 Cal Check	0.099	23:42:48
Air Blank	0.000	23:43:18
Subject Test	0.026*	23:46:25
Air Blank	0.000	23:46:56
Air Blank	0.000	23:47:23
Subject Test	XXX**	23:47:59
Air Blank	0.000	23:48:33

\*Deficient Sample

\*\*Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

10/18/2016

23:49:43

-----  
Standard Lot#: 28515100A1

Last Changed By: W. RYAN #1100  
-----

QAS: W. RYAN #1100

GOODYEAR PD  
-----

Operator: W. RYAN #1100

GOODYEAR PD  
-----

Test	g/210L	Time
Air Blank	0.000	23:50:13
0.100 Cal Check	0.098	23:50:34
Air Blank	0.000	23:51:04

Preventative Maintenance  
Performed -- Timer Reset