

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W. T. RYAN #1100 AGENCY GOODYEAR POLICE DEP.  
DATE 11-15-2017 TIME 1447 HRS  
INTOXILYZER SERIAL # 80-001858 LOCATION 11 N 145TH AVE, GOODYEAR AZ

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0. 100 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W. T. Ryan #1100

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W.T. RYAN #1100 AGENCY GOODYEAR POLICE DEPT

DATE 11-26-17 TIME 1928

INTOXILYZER SERIAL # 80-001858 LOCATION 11 N 145TH AVE GOODYEAR AZ

(G) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.  
OR

Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$

(G) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"

(G) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.

(G) 4. Air blank completed.

(G) 5. Calibration check completed. Test results 0. 099 AC.

(G) 6. Air blank completed.

(G) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W.T. Ryan 1100

INTOXILYZER 8000  
Location: 11 N 145TH AVE  
Serial Number: 80-001858  
Core Version: 8105.48  
11/26/2017 19:28:15

-----  
Standard Lot#: 23016100A1  
Last Changed By: W. RYAN #1100  
-----

QAS: W. RYAN #1100  
GOODYEAR PD  
-----

Operator: W. RYAN #1100  
GOODYEAR PD  
-----

Test	g/210L	Time
Air Blank	0.000	19:28:54
0.100 Cal Check	0.099	19:29:14
Air Blank	0.000	19:29:44

Preventative Maintenance  
Performed -- Timer Reset

INTOXILYZER 8000

Location: 11 N 145TH AVE

Serial Number: 80-001858

Core Version: 8105.48

11/15/2017

14:47:46

-----  
Standard Lot#: 23016100A1

Last Changed By: W. RYAN #1100  
-----

QAS: W. RYAN #1100

GOODYEAR PD  
-----

Operator: W. RYAN #1100

GOODYEAR PD  
-----

Test	g/210L	Time
Air Blank	0.000	14:48:17
0.100 Cal Check	0.100	14:48:38
Air Blank	0.000	14:49:08

Preventative Maintenance  
Performed -- Timer Reset