

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W.T. RYAN 1100 AGENCY GOODYEAR P.D.
DATE 8-7-13 TIME 1236
INTOXILYZER SERIAL # 80-000312 LOCATION FIRE 4

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.10 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0. 098 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W.T. Ryan 1100

INTOXILYZER 8500

Location: 1111 S LICHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

08/07/2013

12:36:15

Standard Lot#: 32012100A1

Last Changed By: M. GUILBAULT #1144

OAS: W. RYAN #1100

GOODYEAR PD

Operator: W. RYAN #1100

GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	12:36:53
0.100 Cal Check	0.098	12:37:14
Air Blank	0.000	12:37:44

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST M. GUTIERREZ, 1144 AGENCY 6007 EAV PD
DATE 8/15/13 TIME 1928
INTOXILYZER SERIAL # 82-000312 LOCATION 10701 S ESTRELLA PKWY

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
OR

Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$

- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
(X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
(X) 4. Air blank completed.
(X) 5. Calibration check completed. Test results 0. 098 AC.
(X) 6. Air blank completed.
(X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE MS 1144

INTOXILYZER 8000

Location: 10701 S ESTRELLA PKW

Serial Number: 80-000312

Core Version: 8105.48

08/15/2013

19:28:51

Standard Lot#: 32012100A1

Last Changed By: M. GUILBAULT #1144

QAS: M. GUILBAULT #1144

GOODYEAR PD

Operator: M. GUILBAULT #1144

GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	19:29:29
0.100 Cal Check	0.098	19:29:50
Air Blank	0.000	19:30:20

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST M. GUSMAN AGENCY GOODYEAR PD
DATE 8/15/13 TIME 1930
INTOXILYZER SERIAL # 80-000312 LOCATION 10701 S ESTRELLA PKWY

☒ 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- ☒ 1. Clock time check.
☒ 2. Date check.

OPERATIONAL TESTS

- ☒ 1. Alcohol-free subject test result 0. 000 AC.
☒ 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
☒ 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
☒ 4. Standard Calibration Check standard 0. 100 AC. Result 0. 097 AC.

Instrument is operating properly and accurately. YES ☒ NO ☐

COMMENTS

SIGNATURE MA 1144

INTOXILYZER 8000

Location: 10701 S ESTRELLA PKW

Serial Number: 80-000312

Core Version: 8105.48

08/15/2013

19:30:31

Standard Lot#: 32012100A1

Last Changed By: M. GUILBAULT #1144

QAS: M. GUILBAULT #1144

GOODYEAR PD

Operator: M. GUILBAULT #1144

GOODYEAR PD

Subject: TEST,TEST

DOB: 01/01/1990

Sex: M Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	19:31:17
Diagnostic Test	Pass	19:31:52
Air Blank	0.000	19:32:19
0.100 Cal Check	0.098	19:32:40
Air Blank	0.000	19:33:10
Subject Test	0.000	19:33:26
Air Blank	IPS*	19:33:34
Air Blank	RFI**	19:33:42

*Improper Sample

**RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: 10701 S ESTRELLA PKW
Serial Number: 80-000312
Core Version: 8105.48
08/15/2013

19:34:04

Standard Lot#: 32012100A1
Last Changed By: M. GUILBAULT #1144

QAS: M. GUILBAULT #1144
GOODYEAR PD

Operator: M. GUILBAULT #1144
GOODYEAR PD

Subject: TEST,TEST
DOB: 10/10/1990
Sex: M Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	19:34:50
Diagnostic Test	Pass	19:35:25
Air Blank	ABT*	19:35:33
Air Blank	0.000	19:36:01

*Sequence Aborted

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: 10701 S ESTRELLA PKW

Serial Number: 80-000312

Core Version: 8105.48

08/15/2013

19:36:15

Standard Lot#: 32012100A1

Last Changed By: M. GUILBAULT

#1144

QAS: M. GUILBAULT

#1144

GOODYEAR PD

Operator: M. GUILBAULT

#1144

GOODYEAR PD

Subject: TEST,TEST

DOB: 10/10/1990

Sex: M

Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	19:37:04
Diagnostic Test	Pass	19:37:39
Air Blank	0.000	19:38:07
0.100 Cal Check	0.098	19:38:28
Air Blank	0.000	19:38:58
Subject Test	0.019*	19:42:05
Air Blank	0.000	19:42:37
Air Blank	0.000	19:43:04
Subject Test	XXX**	19:43:31
Air Blank	0.000	19:44:05

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST M. G. CLARK AGENCY Goodman PD
DATE 8/15/13 1144 TIME 1944
INTOXILYZER SERIAL # 80-000312 LOCATION 10701 S Elmwood Ave

- (1) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR

Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$

- (1) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
(1) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
(1) 4. Air blank completed.
(1) 5. Calibration check completed. Test results 0. 097 AC.
(1) 6. Air blank completed.
(1) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE [Signature] 1144

INTOXILYZER 8000

Location: 10701 S ESTRELLA PKW

Serial Number: 80-000312

Core Version: 8105.48

08/15/2013

19:44:19

Standard Lot#: 32012100A1

Last Changed By: M. GUILBAULT #1144

QAS: M. GUILBAULT #1144

GOODYEAR PD

Operator: M. GUILBAULT #1144

GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	19:44:48
0.100 Cal Check	0.097	19:45:09
Air Blank	0.000	19:45:39

Preventative Maintenance
Performed -- Timer Reset