

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST M. GUELHAULT AGENCY GOODYEAR PD  
DATE 7/14/10 TIME 1316  
INTOXILYZER SERIAL # 80-000312 LOCATION 6AD (VEMEDA)

- 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- 4. Air blank completed.
- 5. Calibration check completed. Test results 0. 100 AC.
- 6. Air blank completed.
- 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE [Signature] 1144

INTOXILYZER 8000  
Location: GOODYEAR PD VENIDA  
Serial Number: 80-000312  
Core Version: 8105.48  
07/14/2010

13:16:28

-----  
Standard Lot#: 672733  
Last Changed By: M. GUILBAULT #1144  
-----

QAS: M. GUILBAULT #1144  
GOODYEAR PD  
-----

Operator: M. GUILBAULT #1144  
GOODYEAR PD  
-----

Test	g/210L	Time
Air Blank	0.000	13:17:12
0.100 Cal Check	0.100	13:17:33
Air Blank	0.000	13:18:02

Preventative Maintenance  
Performed -- Timer Reset

  
1144