

EXHIBIT 2

THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R9-14-404(A)

ARIZONA DEPARTMENT OF HEALTH SERVICES

STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

AGENCY GOODYEAR PD
DATE 6-11-2005 TIME 1840
INTOXILYZER SERIAL NO. 80-000312 LOCATION GOODYEAR PD BOOKING ROOM
QA SPECIALIST J. VALLANDINGHAM #981
(print name)

- (✓) 1. Ensure dry gas tank is attached to instrument and contains a known alcohol standard .100 AC.
- OR
- (✓) 2. Pour a standard alcohol solution of known value, _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 3. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 4. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 5. Air blank completed.
- (✓) 6. Calibration check completed. Test results 0. 099 AC.
- (✓) 7. Air blank completed.
- (✓) 8. Remove printed record. Attach the record to the completed checklist.

SIGNATURE: _____



INTOXILYZER 8000

Location: GOODYEAR POLICE DEPT

Serial Number: 80-000312

06/11/2005

18:40:49


Standard Lot#: 422601G

Last Changed By: W. WILL #974

QAS: J. VALLANDINGHAM #981

GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	18:41:17
Cal Check	0.099	18:41:35
Air Blank	0.000	18:42:05

 981

Operator's Signature