

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST M. GUEHART 1144 AGENCY GOOD TOWN PD
DATE 6/6/13 TIME 0104
INTOXILYZER SERIAL # PD-000312 LOCATION 1111 S LITCHFIELD

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution -100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (X) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0. 102 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE [Signature] 1144

INTOXILYZER 8000

Location: 1111 S LICHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

06/06/2013

01:04:36

Standard Lot#: 13712100A2

Last Changed By: M. GUILBAULT #1144

QAS: M. GUILBAULT #1144

GOODYEAR PD

Operator: M. GUILBAULT #1144

GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	01:05:15
0.100 Cal Check	0.102	01:05:36
Air Blank	0.000	01:06:06

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST M. GILBERT 1144 AGENCY Goodman PD
DATE 4/6/13 TIME 0108
INTOXILYZER SERIAL # PD-000312 LOCATION 1111 S LITCHFIELD RD

- (P) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (P) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (P) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (P) 4. Air blank completed.
- (P) 5. Calibration check completed. Test results 0. 099 AC.
- (P) 6. Air blank completed.
- (P) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE [Signature]

INTOXILYZER 8000

Location: 1111 S LICHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

06/06/2013

01:08:45

Standard Lot#: 32012100A1

Last Changed By: M. GUILBAULT #1144

QAS: M. GUILBAULT #1144

GOODYEAR PD

Operator: M. GUILBAULT #1144

GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	01:09:15
0.100 Cal Check	0.099	01:09:36
Air Blank	0.000	01:10:06

Preventative Maintenance
Performed -- Timer Reset



7 Eastgate Dr. • P.O. Box 790 • Jacksonville, IL 62651-0790
217-245-2183 • Fax: 217-243-7634 • www.ilmoproducts.com

Certificate of Analysis

Certificate ID: 4198
Part #: BAC105L100T
Cylinder Size: 105L
Lot Number: 32012100A1
Expiration: 1/1/2015

0.100 BAC (For use with breath alcohol testing instruments)

Contents: 105 Liters @ 1000 psig 70°F (21°C)

Component:	Concentration:	Accuracy:	Method:
Ethanol	260.5 ppm	+/- 0.002 or 2%	NDIR
Nitrogen	Balance	BAC whichever is greater	

*NIST Standard Reference Material
Certification of NTRM Batch No. 091602
Nominal 210 µmol/mol Ethanol in Nitrogen
for ILMO Products Co., Jacksonville, IL

Jacob Matthes
Specialty Gas Lab Tech

12-03-12
Date

Distributed by: CMI Inc.
316 East Ninth Street
Owensboro, KY 42303
Phone 866-835-0690
www.alcoholtest.com

