

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST M. G. GIBSON 1144 AGENCY GOODYEAR POLICE DEPT.  
DATE 3/16/12 TIME 1000  
INTOXILYZER SERIAL # 80-000312 LOCATION 10701 S ESTRELLA PKWY

1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution \_\_\_\_\_ AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"  
 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.  
 4. Air blank completed.  
 5. Calibration check completed. Test results 0. 102 AC.  
 6. Air blank completed.  
 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE \_\_\_\_\_

INTOXILYZER 8000  
Location: 10701 S ESTRELLA  
Serial Number: 80-000312  
Core Version: 8105.48  
03/16/2012

10:00:39

-----  
Standard Lot#: 06011100A1  
Last Changed By: M. GUILBAULT #1144  
-----

QAS: M. GUILBAULT #1144  
GOODYEAR PD  
-----

Operator: M. GUILBAULT #1144  
GOODYEAR PD  
-----

Test	g/210L	Time
Air Blank	0.000	10:01:10
0.100 Cal Check	0.102	10:01:31
Air Blank	0.000	10:02:00

Preventative Maintenance  
Performed -- Timer Reset