

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W.T. RYAN #1100 AGENCY GOODYEAR POLICE DEPT

DATE 4-1-2019 TIME 1024 HRS

INTOXILYZER SERIAL # 80-001858 LOCATION 11 N 145TH AVE, GOODYEAR AZ 85338

(✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.

OR

Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$

- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0. 101 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W.T. Ryan #1100

INTOXILYZER 8000

Location: 11 N 145TH AVE

Serial Number: 80-001858

Core Version: 8105.48

04/01/2019

10:24:41

-----  
Standard Lot#: 10818100A1

Last Changed By: m. guilbault #1144

-----  
QAS: w. ryan #1100

goodyear pd

-----  
Operator: w. ryan #1100

goodyear pd

-----  
Test                      g/210L                      Time  
-----  
Air Blank                      0.000                      10:25:17  
0.100 Cal Check                0.101                      10:25:37  
Air Blank                      0.000                      10:26:08

Preventative Maintenance  
Performed -- Timer Reset