

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST M. GUSAROVA 1144 AGENCY GOODYEAR PD

DATE 5/15/2012 TIME 1916

INTOXILYZER SERIAL # 80-000312 LOCATION 1111 S LITCHFIELD RD

- ☒ 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution. 100 AC.
OR

Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$

- ☒ 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
☒ 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
☒ 4. Air blank completed.
☒ 5. Calibration check completed. Test results 0. 102 AC.
☒ 6. Air blank completed.
☒ 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE [Signature] 1144

INTOXILYZER 8000
Location: 1111 S LICHFIELD RD
Serial Number: 80-000312
Core Version: 8105.48
05/15/2012

19:16:01

Standard Lot#: 34011100A1
Last Changed By: M. GUILBAULT #1144

QAS: M. GUILBAULT #1144
GOODYEAR PD

Operator: M. GUILBAULT #1144
GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	19:16:36
0.100 Cal Check	0.102	19:16:56
Air Blank	0.000	19:17:27

Preventative Maintenance
Performed -- Timer Reset