

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W. T. Ryan #1100 AGENCY GOODYEAR POLICE DEPT

DATE 12-2-2019 TIME 1037 HRS

INTOXILYZER SERIAL # 90-000312 LOCATION 11 N 145TH AVE, GOODYEAR AZ 85338

(✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
OR

Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$

- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
(✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
(✓) 4. Air blank completed.
(✓) 5. Calibration check completed. Test results 0. 097 AC.
(✓) 6. Air blank completed.
7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W. T. Ryan #1100

INTOXILYZER 8000
Location: 11 N 145TH AVE
Serial Number: 80-600312
Core Version: 8105.48
12/02/2019 10:37:59

Standard Lot#: 10818100A1
Last Changed By: W. RYAN #1100

DAS: W. RYAN #1100
GOODYEAR PD

Operator: W. RYAN #1100
GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	10:37:43
0.100 Cal Check	0.097	10:38:04
Air Blank	0.000	10:38:34


Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST K. Miyazaki 1139 AGENCY Goodyear PD
DATE 12/12/19 TIME 0351
INTOXILYZER SERIAL # 80-000312 LOCATION 11 N 145TH AVE

- () 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- () 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- () 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- () 4. Air blank completed.
- () 5. Calibration check completed. Test results 0. 097 AC.
- () 6. Air blank completed.
- () 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE  1139

INTOXILYZER 8000
Location: 11 N 145TH AVE
Serial Number: 80-000312
Core Version: 8105.48
12/12/2019 03:51:11

Standard Lot#: 10018100A1
Last Changed By: W. RYAN #1100

OAS: K. MIYAZATO #1139
GOODYEAR PD

Operator: K. MIYAZATO #1139
GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	03:51:45
0.100 Cal Check	0.097	03:52:06
Air Blank	0.000	03:52:36

Preventative Maintenance
Performed -- Timer Reset