

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Will AGENCY GOODYEAR PD
DATE 10/07/2019 TIME 1242
INTOXILYZER SERIAL # 80-001858 LOCATION GPD

- (u) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
OR

Pour a standard alcohol concentration solution 100 AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$

- (u) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
(u) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
(u) 4. Air blank completed.
(u) 5. Calibration check completed. Test results 0. 101 AC.
(u) 6. Air blank completed.
(u) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE [Signature]

INTOXILYZER 8000

Location: GOODYEAR POLICE DEPT

Serial Number: 80-001858

10/07/2009

12:41:41

Standard Lot#: 562576

Last Changed By: M. GUILBAULT #1144

QAS: W. WILL #974

GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	12:42:09
Cal Check	0.101	12:42:27
Air Blank	0.000	12:42:57

Operator's Signature