

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST N. WILL AGENCY GOODYEAR PD
DATE 10/29/2013 TIME 0955
INTOXILYZER SERIAL # 80-001850 LOCATION GOODYEAR PD

- ☒ 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- ☒ 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- ☒ 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- ☒ 4. Air blank completed.
- ☒ 5. Calibration check completed. Test results 0. 100 AC.
- ☒ 6. Air blank completed.
- ☒ 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE _____

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

10/29/2013

09:55:06

Standard Lot#: 34011100A1

Last Changed By: M. GUILBAULT #1144

QAS: W. WILL #974

GOODYEAR PD

Operator: W. WILL #974

GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	09:55:38
0.100 Cal Check	0.100	09:55:59
Air Blank	0.000	09:56:28

Preventative Maintenance

Performed -- Timer Reset