

EXHIBIT G-4  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST K M YAZATO 1139 AGENCY G 00 DY 22R  
DATE 9/30/22 TIME 0503  
INTOXILYZER SERIAL # 80-000312 LOCATION 11 N 145TH AVE

(  ) 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- (  ) 1. Clock time check.  
(  ) 2. Date check.

OPERATIONAL TESTS

- (  ) 1. Alcohol-free subject test result 0. 000 AC.  
(  ) 2. Error recognition logic system functioning.  
Not a Successfully Completed Test Sequence printed  
(  ) 3. Proper sample recognition system.  
Not a Successfully Completed Test Sequence printed  
Deficient sample printed.  
(  ) 4. Standard Calibration Check standard 0. 100 AC. Result 0. 097 AC.

Instrument is operating properly and accurately. YES  NO

COMMENTS

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

SIGNATURE K M YAZATO 1139

INTOXILYZER 8000

Location: 11 N 145TH AVE

Serial Number: 80-000312

Core Version: 8105.48

09/30/2022

05:03:24

---

Standard Lot#: 28021100A1

Last Changed By: K. MIYAZATO #1139

---

QAS: K. MIYAZATO #1139

GOODYEAR PD

---

Operator: K. MIYAZATO #1139

GOODYEAR PD

---

Subject: SQAP,TEST

DOB: 04/02/1973

Sex: M Weight: 200

---

15 Minute Deprivation Period? Yes

---

| Test            | g/210L | Time     |
|-----------------|--------|----------|
| Air Blank       | 0.000  | 05:04:51 |
| Diagnostic Test | Pass   | 05:05:26 |
| Air Blank       | 0.000  | 05:05:53 |
| 0.100 Cal Check | 0.099  | 05:06:14 |
| Air Blank       | 0.000  | 05:06:45 |
| Subject Test    | 0.000  | 05:07:24 |
| Air Blank       | ABT*   | 05:07:31 |
| Air Blank       | 0.000  | 05:07:59 |

\*Sequence Aborted

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: 11 N 145TH AVE

Serial Number: 80-000312

Core Version: 8105.48

09/30/2022

05:08:01

---

Standard Lot#: 28021100A1

Last Changed By: K. MIYAZATO #1139

---

QAS: K. MIYAZATO #1139

GOODYEAR PD

---

Operator: K. MIYAZATO #1139

GOODYEAR PD

---

Subject: SQAP,TEST

DOB: 04/02/1973

Sex: M Weight: 200

---

15 Minute Deprivation Period? Yes

---

| Test      | g/210L | Time     |
|-----------|--------|----------|
| Air Blank | IPS*   | 05:08:40 |
| Air Blank | 0.000  | 05:09:09 |

\*Improper Sample

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: 11 N 145TH AVE

Serial Number: 80-000312

Core Version: 8105.48

09/30/2022

05:09:12

---

Standard Lot#: 28021100A1

Last Changed By: K. MIYAZATO #1139

---

QAS: K. MIYAZATO #1139

GOODYEAR PD

---

Operator: K. MIYAZATO #1139

GOODYEAR PD

---

Subject: SQAP,TEST

DOB: 04/02/1973

Sex: M Weight: 200

---

15 Minute Deprivation Period? Yes

---

| Test      | g/210L | Time     |
|-----------|--------|----------|
| Air Blank | RFI*   | 05:09:45 |
| Air Blank | 0.000  | 05:10:13 |

\*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000  
Location: 11 N 145TH AVE  
Serial Number: 80-000312  
Core Version: 8105.48  
09/30/2022

05:10:15

---

Standard Lot#: 28021100A1  
Last Changed By: K. MIYAZATO #1139

---

QAS: K. MIYAZATO #1139  
GOODYEAR PD

---

Operator: K. MIYAZATO #1139  
GOODYEAR PD

---

Subject: SQAP,TEST  
DOB: 04/02/1973  
Sex: M Weight: 200

---

15 Minute Deprivation Period? Yes

---

| Test            | g/210L | Time     |
|-----------------|--------|----------|
| Air Blank       | 0.000  | 05:11:03 |
| Diagnostic Test | Pass   | 05:11:38 |
| Air Blank       | 0.000  | 05:12:05 |
| 0.100 Cal Check | 0.099  | 05:12:26 |
| Air Blank       | 0.000  | 05:12:56 |
| Subject Test    | 0.231* | 05:16:04 |
| Air Blank       | 0.000  | 05:16:39 |
| Air Blank       | 0.000  | 05:17:07 |
| Subject Test    | XXX**  | 05:17:21 |
| Air Blank       | 0.000  | 05:17:55 |

\*Deficient Sample

\*\*Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST K Miyazawa 1139 AGENCY Goodyear PD  
DATE 9/30/2022 TIME 0518  
INTOXILYZER SERIAL # 80-000312 LOCATION 11 N 145 TH AVE

- () 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- () 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- () 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- () 4. Air blank completed.
- () 5. Calibration check completed. Test results 0. 097 AC.
- () 6. Air blank completed.
- () 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE K Miyazawa 1139

INTOXILYZER 8000  
Location: 11 N 145TH AVE  
Serial Number: 80-000312  
Core Version: 8105.48  
09/30/2022 05:18:15

-----  
Standard Lot#: 28021100A1  
Last Changed By: K. MIYAZATO #1139  
-----

QAS: K. MIYAZATO #1139  
GOODYEAR PD  
-----

Operator: K. MIYAZATO #1139  
GOODYEAR PD  
-----

| Test            | g/210L | Time     |
|-----------------|--------|----------|
| Air Blank       | 0.000  | 05:18:45 |
| 0.100 Cal Check | 0.097  | 05:19:06 |
| Air Blank       | 0.000  | 05:19:36 |

Preventative Maintenance  
Performed -- Timer Reset