

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W.T. Ryan #1100 AGENCY GOODYEAR P.D.  
DATE 5-8-15 TIME 2134 HRS  
INTOXILYZER SERIAL # 80-000312 LOCATION 1111 S LITCHFIELD RD GOODYEAR AZ

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (SS) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"  
(SS) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.  
(SS) 4. Air blank completed.  
(SS) 5. Calibration check completed. Test results 0. 101 AC.  
(SS) 6. Air blank completed.  
7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W.T. Ryan #1100

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

05/08/2015

21:34:53

-----  
Standard Lot#: 26614100A6

Last Changed By: W. RYAN #1100

-----  
QAS: W. RYAN #1100

GOODYEAR PD

-----  
Operator: W. RYAN #1100

GOODYEAR PD

-----  
Test                      g/210L                      Time  
-----  
Air Blank                      0.000                      21:35:48  
0.100 Cal Check                0.101                      21:36:09  
Air Blank                      0.000                      21:36:39

Preventative Maintenance  
Performed -- Timer Reset

EXHIBIT G-4  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST W.T. RYAN 1100 AGENCY GOODYEAR P.D.

DATE 5-8-15 TIME 2144

INTOXILYZER SERIAL # 80-000312 LOCATION 1111 S LITCHFIELD RD GOODYEAR AZ

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- 1. Clock time check.
- 2. Date check.

OPERATIONAL TESTS

- 1. Alcohol-free subject test result 0. 000 AC.
- 2. Error recognition logic system functioning.  
Not a Successfully Completed Test Sequence printed
- 3. Proper sample recognition system.  
Not a Successfully Completed Test Sequence printed  
Deficient sample printed.
- 4. Standard Calibration Check standard 0. 100 AC. Result 0. 100 AC.

Instrument is operating properly and accurately. YES  NO

COMMENTS

NO ISSUES

SIGNATURE W.T. Ryan 1100

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

05/08/2015

21:44:42

---

Standard Lot#: 26614100A6

Last Changed By: W. RYAN #1100

---

QAS: W. RYAN #1100

GOODYEAR PD

---

Operator: W. RYAN #1100

GOODYEAR PD

---

Subject: TEST,TEST

DOB: 05/08/1959

Sex: M

Weight: 180

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	21:45:36
Diagnostic Test	Pass	21:46:11
Air Blank	0.000	21:46:38
0.100 Cal Check	0.101	21:46:59
Air Blank	0.000	21:47:28
Subject Test	0.000	21:47:46
Air Blank	0.000	21:48:13
Wait	ABT*	
Air Blank	0.000	21:48:51

\*Sequence Aborted

**Not a Successfully Completed Test Sequence**

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

05/08/2015

21:54:20

---

Standard Lot#: 26614100A6

Last Changed By: W. RYAN #1100

---

QAS: W. RYAN #1100

GOODYEAR PD

---

Operator: W. RYAN #1100

GOODYEAR PD

---

Subject: TEST,TEST

DOB: 05/08/1959

Sex: M

Weight: 180

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	IPS*	21:55:05
Air Blank	0.000	21:55:33

\*Improper Sample

**Not a Successfully Completed Test Sequence**

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

05/08/2015

21:56:22

---

Standard Lot#: 26614100A6

Last Changed By: W. RYAN

#1100

---

QAS: W. RYAN

#1100

GOODYEAR PD

---

Operator: W. RYAN

#1100

GOODYEAR PD

---

Subject: TEST,TEST

DOB: 05/08/1959

Sex: M

Weight: 180

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	RFI*	21:57:05
Air Blank	0.000	21:57:33

\*RFI Detect

**Not a Successfully Completed Test Sequence**

INTOXILYZER 8000

Location: 1111 S LITCHEFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

05/08/2015

21:57:55

---

Standard Lot#: 26614100A6

Last Changed By: W. RYAN #1100

---

QAS: W. RYAN #1100

GOODYEAR PD

---

Operator: W. RYAN #1100

GOODYEAR PD

---

Subject: TEST,TEST

DOB: 05/08/1959

Sex: M

Weight: 180

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	21:58:46
Diagnostic Test	Pass	21:59:21
Air Blank	0.000	21:59:48
0.100 Cal Check	0.100	22:00:09
Air Blank	0.000	22:00:39
Subject Test	0.014*	22:03:46
Air Blank	0.000	22:04:16
Air Blank	0.000	22:04:43
Subject Test	XXX**	22:05:13
Air Blank	0.000	22:05:47

\*Deficient Sample

\*\*Invalid Sample

Begin new deprivation period

**Not a Successfully Completed Test Sequence**

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

05/08/2015

22:06:33

-----  
Standard Lot#: 26614100A6

Last Changed By: W. RYAN #1100  
-----

QAS: W. RYAN #1100

GOODYEAR PD  
-----

Operator: W. RYAN #1100

GOODYEAR PD  
-----

Test	g/210L	Time
Air Blank	0.000	22:07:04
0.100 Cal Check	0.100	22:07:25
Air Blank	0.000	22:07:55

Preventative Maintenance  
Performed -- Timer Reset



EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W.T. Ryan 1100 AGENCY GOODYEAR POLICE DEPT  
DATE 5-19-15 TIME 1312  
INTOXILYZER SERIAL # 80-000812 LOCATION 1111 S LITCHFIELD RD GOODYEAR AZ

- (S) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (M) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (M) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (M) 4. Air blank completed.
- (M) 5. Calibration check completed. Test results 0. 102 AC.
- (M) 6. Air blank completed.
- (M) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W.T. Ryan 1100

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

05/19/2015

13:12:56

-----  
Standard Lot#: 26614100A6

Last Changed By: W. RYAN #1100  
-----

QAS: W. RYAN #1100

GOODYEAR PD'  
-----

Operator: W. RYAN #1100

GOODYEAR PD  
-----

Test	g/210L	Time
Air Blank	0.000	13:13:27
0.100 Cal Check	0.102	13:13:48
Air Blank	0.000	13:14:17

Preventative Maintenance  
Performed -- Timer Reset

EXHIBIT G-4  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST W.T. RYAN #1100 AGENCY GOODYEAR POLICE DEPT  
DATE 5-19-15 TIME 1344  
INTOXILYZER SERIAL # 80-000312 LOCATION 1111 S LITCHFIELD RD GOODYEAR AZ

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

1. Clock time check.  
 2. Date check.

OPERATIONAL TESTS

1. Alcohol-free subject test result 0. 000 AC.  
 2. Error recognition logic system functioning.  
Not a Successfully Completed Test Sequence printed  
 3. Proper sample recognition system.  
Not a Successfully Completed Test Sequence printed  
Deficient sample printed.  
 4. Standard Calibration Check standard 0. 100 AC. Result 0. 100 AC.

Instrument is operating properly and accurately. YES  NO

COMMENTS

TAKEN OUT OF SERVICE FOR YEARLY MAINTENANCE  
AT DPS

SIGNATURE

W.T. Ryan 1100

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

05/19/2015

13:44:10

---

Standard Lot#: 26614100A6

Last Changed By: W. RYAN #1100

---

QAS: W. RYAN #1100

GOODYEAR PD

---

Operator: W. RYAN #1100

GOODYEAR PD

---

Subject: TEST,TEST

DOB: 05/19/1959

Sex: M

Weight: 180

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	13:45:13
Diagnostic Test	Pass	13:45:48
Air Blank	0.000	13:46:15
0.100 Cal Check	0.101	13:46:36
Air Blank	0.000	13:47:05
Subject Test	0.000	13:47:22
Air Blank	0.000	13:47:49
Wait	ABT*	
Air Blank	0.000	13:48:24

\*Sequence Aborted

**Not a Successfully Completed Test Sequence**

INTOXILYZER 8000  
Location: 1111 S LITCHFIELD RD  
Serial Number: 80-000312  
Core Version: 8105.48  
05/19/2015

13:48:31

---

Standard Lot#: 26614100A6  
Last Changed By: W. RYAN #1100

---

QAS: W. RYAN #1100  
GOODYEAR PD

---

Operator: W. RYAN #1100  
GOODYEAR PD

---

Subject: TEST,TEST  
DOB: 05/19/1959  
Sex: M Weight: 180

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	IPS*	13:49:08
Air Blank	0.000	13:49:36

\*Improper Sample

**Not a Successfully Completed Test Sequence**

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

05/19/2015

13:49:56

---

Standard Lot#: 26614100A6

Last Changed By: W. RYAN #1100

---

QAS: W. RYAN #1100

GOODYEAR PD

---

Operator: W. RYAN #1100

GOODYEAR PD

---

Subject: TEST,TEST

DOB: 05/19/1959

Sex: M

Weight: 180

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	RFI*	13:50:30
Air Blank	0.000	13:50:59

\*RFI Detect

**Not a Successfully Completed Test Sequence**

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

05/19/2015

13:51:04

---

Standard Lot#: 26614100A6

Last Changed By: W. RYAN #1100

---

QAS: W. RYAN #1100

GOODYEAR PD

---

Operator: W. RYAN #1100

GOODYEAR PD

---

Subject: TEST,TEST

DOB: 05/19/1959

Sex: M

Weight: 180

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	13:52:07
Diagnostic Test	Pass	13:52:42
Air Blank	0.000	13:53:10
0.100 Cal Check	0.101	13:53:30
Air Blank	0.000	13:54:00
Subject Test	0.057*	13:57:08
Air Blank	0.000	13:57:39
Air Blank	0.000	13:58:07
Subject Test	RGE**	13:58:24
Air Blank	0.000	13:59:07

\*Deficient Sample

\*\*Range Exceeded

**Not a Successfully Completed Test Sequence**

INTOXILYZER 8000  
Location: 1111 S LITCHFIELD RD  
Serial Number: 80-000312  
Core Version: 8105.48  
05/19/2015 13:59:11

---

Standard Lot#: 26614100A6  
Last Changed By: W. RYAN #1100

---

QAS: W. RYAN #1100  
GOODYEAR PD

---

Operator: W. RYAN #1100  
GOODYEAR PD

---

Subject: TEST,TEST  
DOB: 05/19/1959  
Sex: M Weight: 180

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	14:00:06
Diagnostic Test	Pass	14:00:41
Air Blank	0.000	14:01:09
0.100 Cal Check	0.100	14:01:29
Air Blank	0.000	14:01:59
Subject Test	0.103*	14:05:07
Air Blank	0.000	14:05:39
Air Blank	0.000	14:06:06
Subject Test	0.133	14:06:23
Air Blank	0.000	14:06:58
Wait	RFI**	
Air Blank	0.000	14:09:13

\*Deficient Sample

\*\*RFI Detect

**Not a Successfully Completed Test Sequence**



INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

05/19/2015

14:09:16

---

Standard Lot#: 26614100A6

Last Changed By: W. RYAN #1100

---

QAS: W. RYAN #1100

GOODYEAR PD

---

Operator: W. RYAN #1100

GOODYEAR PD

---

Subject: TEST,TEST

DOB: 05/19/1959

Sex: M

Weight: 180

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	14:10:09
Diagnostic Test	Pass	14:10:44
Air Blank	0.000	14:11:11
0.100 Cal Check	0.100	14:11:32
Air Blank	0.000	14:12:02
Subject Test	0.064*	14:15:10
Air Blank	0.000	14:15:42
Air Blank	0.000	14:16:09
Subject Test	RGE**	14:16:25
Air Blank	0.000	14:17:03

\*Deficient Sample

\*\*Range Exceeded

**Not a Successfully Completed Test Sequence**

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

05/19/2015

14:17:08

---

Standard Lot#: 26614100A6

Last Changed By: W. RYAN #1100

---

QAS: W. RYAN #1100

GOODYEAR PD

---

Operator: W. RYAN #1100

GOODYEAR PD

---

Subject: TEST,TEST

DOB: 05/19/1959

Sex: M

Weight: 180

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	14:18:02
Diagnostic Test	Pass	14:18:37
Air Blank	0.000	14:19:04
0.100 Cal Check	0.100	14:19:25
Air Blank	0.000	14:19:55
Subject Test	0.028*	14:23:03
Air Blank	0.000	14:23:34
Air Blank	0.000	14:24:01
Subject Test	XXX**	14:24:18
Air Blank	0.000	14:24:52

\*Deficient Sample

\*\*Invalid Sample

Begin new deprivation period

**Not a Successfully Completed Test Sequence**





ARIZONA DEPARTMENT OF PUBLIC SAFETY

INTOXILYZER MAINTENANCE REPORT

CR NO. I800003120003

Page 1 of 1

**AGENCY** Goodyear Police Department  
Goodyear, AZ 85338  
**OFFICER** RYAN, #1100  
**DATE** May 26, 2015



**INSTRUMENT**

80000312

**INSTRUMENT LOCATION**

Goodyear Police Department

**MAINTENANCE REQUESTED**

Preventative Maintenance

**MAINTENANCE PERFORMED**

*Preventative Maintenance Performed:*

Inspection, Calibration, Verification

A handwritten signature in black ink, appearing to read "Joseph M Slowinski".

---

JOSEPH M SLOWINSKI, #6101, Electronics Technician  
Central Regional Crime Laboratory  
2102 W. Encanto Blvd., Phoenix, AZ 85009  
(602) 223-2394

EXHIBIT G-4  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST W.T. Ryan #1100 AGENCY GOODYEAR P.D.

DATE 5-29-15 TIME 1514

INTOXILYZER SERIAL # 80-000312 LOCATION 1111 S LITCHFIELD RD GOODYEAR AZ

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- 1. Clock time check.
- 2. Date check.

OPERATIONAL TESTS

- 1. Alcohol-free subject test result 0. 000 AC.
- 2. Error recognition logic system functioning.  
Not a Successfully Completed Test Sequence printed
- 3. Proper sample recognition system.  
Not a Successfully Completed Test Sequence printed  
Deficient sample printed.
- 4. Standard Calibration Check standard 0. 100 AC. Result 0. 101 AC.

Instrument is operating properly and accurately. YES  NO

COMMENTS

BROUGHT BACK INTO SERVICE AFTER  
D.P.S. YEARLY MAINT.

SIGNATURE W.T. Ryan 1100

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

05/29/2015

15:14:46

---

Standard Lot#: 26614100A6

Last Changed By: W. RYAN

#1100

---

QAS: W. RYAN

#1100

GOODYEAR PD

---

Operator: W. RYAN

#1100

GOODYEAR PD

---

Subject: TEST,TEST

DOB: 05/29/1959.

Sex: M

Weight: 180

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	15:16:26
Diagnostic Test	Pass	15:17:01
Air Blank	0.000	15:17:28
0.100 Cal Check	0.102	15:17:49
Air Blank	0.000	15:18:19
Subject Test	0.000	15:18:51
Air Blank	0.000	15:19:19
Wait	ABT*	
Air Blank	0.000	15:19:53

\*Sequence Aborted

**Not a Successfully Completed Test Sequence**

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

05/29/2015

15:26:11

---

Standard Lot#: 26614100A6

Last Changed By: W. RYAN #1100

---

QAS: W. RYAN #1100

GOODYEAR PD

---

Operator: W. RYAN #1100

GOODYEAR PD

---

Subject: TEST,TEST

DOB: 05/29/1959

Sex: M Weight: 180

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	IPS*	15:27:33
Air Blank	0.000	15:28:02

\*Improper Sample

**Not a Successfully Completed Test Sequence**

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48 .

05/29/2015

15:31:25

---

Standard Lot#: 26614100A6

Last Changed By: W. RYAN

#1100

---

QAS: W. RYAN

#1100

GOODYEAR PD

---

Operator: W. RYAN .

#1100

GOODYEAR PD

---

Subject: TEST,TEST

DOB: 05/29/1959.

Sex: M

Weight: 180

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	RFI*	15:32:03
Air Blank	0.000	15:32:32

\*RFI Detect

**Not a Successfully Completed Test Sequence**



INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

05/29/2015

15:33:06

---

Standard Lot#: 26614100A6

Last Changed By: W. RYAN #1100

---

QAS: W. RYAN #1100

GOODYEAR PD

---

Operator: W. RYAN #1100

GOODYEAR PD

---

Subject: TEST,TEST

DOB: 05/29/1959

Sex: M

Weight: 180

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	15:34:03
Diagnostic Test	Pass	15:34:38
Air Blank	0.000	15:35:06
0.100 Cal Check	0.101	15:35:27
Air Blank	0.000	15:35:57
Subject Test	0.080*	15:39:04
Air Blank	0.000	15:39:36
Air Blank	0.000	15:40:03
Subject Test	RGE**	15:40:32
Air Blank	0.000	15:41:07

\*Deficient Sample

\*\*Range Exceeded

**Not a Successfully Completed Test Sequence**

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

05/29/2015

15:41:33

---

Standard Lot#: 26614100A6

Last Changed By: W. RYAN #1100

---

QAS: W. RYAN #1100

GOODYEAR PD

---

Operator: W. RYAN #1100

GOODYEAR PD

---

Subject: TEST,TEST

DOB: 05/29/1959

Sex: M Weight: 180

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	15:42:31
Diagnostic Test	Pass	15:43:06
Air Blank	0.000	15:43:34
0.100 Cal Check	0.101	15:43:55
Air Blank	0.000	15:44:25
Subject Test	0.008*	15:47:32
Air Blank	0.000	15:48:00
Air Blank	0.000	15:48:27
Subject Test	XXX**	15:48:51
Air Blank	0.000	15:49:25

\*Deficient Sample

\*\*Invalid Sample

Begin new deprivation period

**Not a Successfully Completed Test Sequence**

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

05/29/2015

15:50:30

-----  
Standard Lot#: 26614100A6

Last Changed By: W. RYAN #1100  
-----

QAS: W. RYAN #1100

GOODYEAR PD  
-----

Operator: W. RYAN #1100

GOODYEAR PD  
-----

Test	g/210L	Time
Air Blank	0.000	15:51:02
0.100 Cal Check	0.101	15:51:23
Air Blank	0.000	15:51:53

Preventative Maintenance  
Performed -- Timer Reset

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W.T. RYAN #1100 AGENCY GOODYEAR P.D.

DATE 5-29-15 TIME 1509

INTOXILYZER SERIAL # 80-000312 LOCATION 1111 S LITCHFIELD RD GOODYEAR AZ

(✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.  
OR

Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$

(✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"

(✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.

(✓) 4. Air blank completed.

(✓) 5. Calibration check completed. Test results 0.101 AC.

(✓) 6. Air blank completed.

(✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W.T. Ryan #1100

DPS Form Exh G-2 (Rev 05-01)

BROUGHT BACK INTO SERVICE AFTER DPS  
YEARLY MAINT.

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

05/29/2015

15:09:08

-----  
Standard Lot#: 26614100A6

Last Changed By: W. RYAN #1100  
-----

QAS: W. RYAN #1100

GOODYEAR PD  
-----

Operator: W. RYAN #1100

GOODYEAR PD  
-----

Test	g/210L	Time
Air Blank	0.000	15:09:37
0.100 Cal Check	0.101	15:09:58
Air Blank	0.000	15:10:28

Preventative Maintenance  
Performed -- Timer Reset