

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W. T. RYAN #1100 AGENCY GOODYEAR POLICE DEPT
DATE 12-17-15 TIME 1813
INTOXILYZER SERIAL # 80-000312 LOCATION 1111 S LITAFIELD RD GOODYEAR AZ

- (M) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (M) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
(M) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
(M) 4. Air blank completed.
(M) 5. Calibration check completed. Test results 0. 102 AC.
(M) 6. Air blank completed.
(M) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W. T. Ryan 1100

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

12/17/2015

18:13:26

Standard Lot#: 16014100A1

Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100

GOODYEAR PD

Operator: W. RYAN #1100

GOODYEAR PD

Test g/210L Time

Air Blank 0.000 18:14:27
0.100 Cal Check 0.102 18:14:48
Air Blank 0.000 18:15:18

Preventative Maintenance
Performed -- Timer Reset

W. Ryan