



ARIZONA DEPARTMENT OF PUBLIC SAFETY

INTOXILYZER MAINTENANCE REPORT

CR NO. I800018580005

Page 1 of 1

AGENCY Goodyear Police Department
 Goodyear, AZ 85338
OFFICER RYAN, #1100
DATE March 11, 2016



INSTRUMENT

80001858

INSTRUMENT LOCATION

Goodyear Police Department

MAINTENANCE REQUESTED

Repair and Preventative Maintenance

MAINTENANCE PERFORMED

Parts Replaced:

Instrument repaired at CMI.

Preventative Maintenance Performed:

Inspection, Calibration, Verification

A handwritten signature in black ink, appearing to read "Robert W. Stephenson".

ROBERT W. STEPHENSON, #5742, Criminalist
Central Regional Crime Laboratory
2102 W. Encanto Blvd., Phoenix, AZ 85009
602-223-2114

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W. T. RYAN #1100 AGENCY GOODYEAR POLICE DEPT
DATE 3-16-16 TIME 1714
INTOXILYZER SERIAL # 80-001858 LOCATION 11115 LITCHFIELD RD GOODYEAR AZ

(X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.106 AC.
OR

Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$

- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
(X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
(X) 4. Air blank completed.
(X) 5. Calibration check completed. Test results 0.099 AC.
(X) 6. Air blank completed.
(X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W. T. Ryan

DPS Form Exh G-2 (Rev 05-01)

BACK IN SVC, STANDARD CHANGE

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

03/16/2016

17:14:05

Standard Lot#: 28515100A1

Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100

GOODYEAR PD

Operator: W. RYAN #1100

GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	17:14:40
0.100 Cal Check	0.099	17:15:01
Air Blank	0.000	17:15:31

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST W.T. RYAN #1100 AGENCY GOODYEAR POLICE DEPT
DATE 3-16-16 TIME 1724
INTOXILYZER SERIAL # 80-001858 LOCATION 1111 S LITCHFIELD RD GOODYEAR AZ

() 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- () 1. Clock time check.
() 2. Date check.

OPERATIONAL TESTS

- () 1. Alcohol-free subject test result 0. 000 AC.
() 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
() 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
() 4. Standard Calibration Check standard 0. 100 AC. Result 0. 099 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS

BROUGHT BACK IN SERVICE AFTER
DPS MAINT, NO ISSUES

SIGNATURE

W.T. Ryan 1100

DPS Form Exh G-4 (Rev 05-01)

BACK IN SERVICE FROM DPS

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

03/16/2016

17:24:28

Standard Lot#: 28515100A1

Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100

GOODYEAR PD

Operator: W. RYAN #1100

GOODYEAR PD

Subject: TEST,TEST

DOB: 03/16/1959

Sex: M

Weight: 180

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	17:25:25
Diagnostic Test	Pass	17:26:00
Air Blank	0.000	17:26:27
0.100 Cal Check	0.100	17:26:48
Air Blank	0.000	17:27:18
Subject Test	0.000	17:27:32
Air Blank	0.000	17:28:00
Wait	ABT*	
Air Blank	0.000	17:28:46

*Sequence Aborted

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

03/16/2016

17:29:10

Standard Lot#: 28515100A1

Last Changed By: W. RYAN

#1100

QAS: W. RYAN

#1100

GOODYEAR PD

Operator: W. RYAN

#1100

GOODYEAR PD

Subject: TEST,TEST

DOB: 03/16/1959

Sex: M

Weight: 180

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	IPS*	17:29:55
Air Blank	0.000	17:30:24

*Improper Sample

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

03/16/2016

17:30:52

Standard Lot#: 28515100A1

Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100

GOODYEAR PD

Operator: W. RYAN #1100

GOODYEAR PD

Subject: TEST,TEST

DOB: 03/16/1959

Sex: M

Weight: 180

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	RFI*	17:31:24
Air Blank	RFI*	17:31:33

*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: 1111 S LITCHFIELD RD
Serial Number: 80-001858
Core Version: 8105.48
03/16/2016 17:32:21

Standard Lot#: 28515100A1
Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100
GOODYEAR PD

Operator: W. RYAN #1100
GOODYEAR PD

Subject: TEST,TEST
DOB: 03/16/1959
Sex: M Weight: 180

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	17:33:22
Diagnostic Test	Pass	17:33:57
Air Blank	0.000	17:34:24
0.100 Cal Check	0.100	17:34:45
Air Blank	0.000	17:35:15
Subject Test	RGE*	17:35:32
Air Blank	0.000	17:36:18

*Range Exceeded

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: 1111 S LITCHFIELD RD
Serial Number: 80-001858
Core Version: 8105.48
03/16/2016 17:36:25

Standard Lot#: 28515100A1
Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100
GOODYEAR PD

Operator: W. RYAN #1100
GOODYEAR PD

Subject: TEST,TEST
DOB: 03/16/1959
Sex: M Weight: 180

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	17:37:21
Diagnostic Test	Pass	17:37:56
Air Blank	0.000	17:38:24
0.100 Cal Check	0.099	17:38:44
Air Blank	0.000	17:39:14
Subject Test	XXX*	17:41:28
Air Blank	0.000	17:42:03

*Invalid Sample
Begin new deprivation period

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

03/16/2016

17:43:56

Standard Lot#: 28515100A1

Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100

GOODYEAR PD

Operator: W. RYAN #1100

GOODYEAR PD

Subject: TEST,TEST

DOB: 03/16/1959

Sex: M

Weight: 180

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	17:44:51
Diagnostic Test	Pass	17:45:26
Air Blank	0.000	17:45:54
0.100 Cal Check	0.099	17:46:15
Air Blank	0.000	17:46:44
Subject Test	0.120*	17:49:52
Air Blank	0.000	17:50:24
Air Blank	0.000	17:50:51
Subject Test	XXX**	17:51:15
Air Blank	0.000	17:51:48

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: 1111 S LITCHFIELD RD
Serial Number: 80-001858
Core Version: 8105.48
03/16/2016 17:52:08

Standard Lot#: 28515100A1
Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100
GOODYEAR PD

Operator: W. RYAN #1100
GOODYEAR PD

Test g/210L Time

Air Blank 0.000 17:52:38
0.100 Cal Check 0.099 17:52:59
Air Blank 0.000 17:53:28

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W.T. RYAN 1100 AGENCY GOODYEAR POLICE DEPT

DATE 3-30-16 TIME 1713 HRS

INTOXILYZER SERIAL # 80-001858 LOCATION 1111 S LITCHFIELD RD GOODYEAR AZ

(S) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
OR

Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$

- (H) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
(H) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
(S) 4. Air blank completed.
(H) 5. Calibration check completed. Test results 0.100 AC.
(H) 6. Air blank completed.
(H) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W.T. Ryan 1100

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

03/30/2016

17:13:57

Standard Lot#: 28515100A1

Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100

GOODYEAR PD

Operator: W. RYAN #1100

GOODYEAR PD

Test g/210L Time

Air Blank 0.000 17:15:32
0.100 Cal Check 0.100 17:15:53
Air Blank 0.000 17:16:22

Preventative Maintenance
Performed -- Timer Reset