EXHIBIT G-4 THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST W. T. RYAY 1100	AGEN	CY GOODY	spe Por	ice Dep.	·/-
DATE 9-2-18		2042			
INTOXILYZER SERIAL # 90-001858	LOCAT	MON [] N /4	STHALE, G	-00 DYGAR	AZ 883
(1. Display Reads "PUSH BUTTON TO START"			,	•	
DIAGNOSTIC TESTS () 1. Clock time check. () 2. Date check.	**				
OPERATIONAL TESTS (\$\frac{1}{2}\$. Alcohol-free subject test result 0. \(\frac{00}{2} \). A 2. Error recognition logic system functioning. Not a Successfully Completed Test Seque (\$\frac{3}{2}\$. Proper sample recognition system. Not a Successfully Completed Test Seque Deficient sample printed. (\$\frac{4}{2}\$. Standard Calibration Check standard 0. \(\frac{100}{2} \). Instrument is operating properly and accurately. YES \(\frac{1}{2} \)	ence printed		AC.		
COMMENTS NO ISSUES					
SIGNATURE W. T. Ryan 1100)	,			
DPS Form Exh G-4 (Rev 05-01)					

Location: 11 N 145TH AVE Serial Number: 80-001858 Core Version: 8105.48

09/02/2018

20:42:20

Standard Lot#: 10818100A1 Last Changed By: W. RYAN	#1100
QAS: W. RYAN GOODYEAR PD	#1100
Operator: W. RYAN GOODYEAR PD	#1100

Subject: TEST, TEST DOB: 09/02/1959

Sex: M

Weight: 185

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	20:43:32
Diagnostic Test	Pass	20:44:07
Air Blank	0.000	20:44:35
0.100 Cal Check	0.100	20:44:55
Air Blank	0.000	20:45:26
Subject Test	0.000	20:45:44
Air Blank	0.000	20:46:11
Wait	ABT*	
Air Blank	0.000	20:46:49

^{*}Sequence Aborted

Location: 11 N 145TH AVE Serial Number: 80-001858 Core Version: 8105.48

09/02/2018 20:48:30

Standard Lot#: 10818100A1

Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100

GOODYEAR PD

Operator: W. RYAN #1100

GOODYEAR PD

Subject: TEST, TEST DOB: 09/02/1959

Sex: M Weight: 185

15 Minute Deprivation Period? Yes

 Test
 g/210L
 Time

 Air Blank
 IPS*
 20:49:12

 Air Blank
 0.000
 20:49:41

^{*}Improper Sample

Location: 11 N 145TH AVE Serial Number: 80-001858 Core Version: 8105.48

09/02/2018

20:50:34

Standard Lot#: 10818100A1

Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100

GOODYEAR PD

Operator: W. RYAN #1100

GOODYEAR PD

Subject: TEST, TEST

DOB: 09/02/1959

Sex: M

Weight: 185

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	RFI*	20:51:23
Air Blank	RFI*	20:51:31

^{*}RFI Detect

Location: 11 N 145TH AVE Serial Number: 80-001858 Core Version: 8105.48

09/02/2018 20:53:53

Standard Lot#: 10818100A1
Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100

GOODYEAR PD

Operator: W. RYAN #1100

GOODYEAR PD

Subject: TEST, TEST DOB: 09/02/1959

Sex: M Weight: 185

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	20:54:51
Diagnostic Test	Pass	20:55:26
Air Blank	0.000	20:55:53
0.100 Cal Check	0.100	20:56:14
Air Blank	0.000	20:56:44
Subject Test	0.111*	20:59:52
Air Blank	0.000	21:00:24
Air Blank	0.000	21:00:51
Subject Test	XXX**	21:01:29
Air Blank	0.000	21:02:04

^{*}Deficient Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

^{**}Invalid Sample

Location: 11 N 145TH AVE Serial Number: 80-001858 Core Version: 8105.48

09/02/2018 21:03:08

Standard Lot#: 10818100A1

Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100

GOODYEAR PD

Operator: W. RYAN #1100

GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	21:03:38
0.100 Cal Check	0.099	21:03:59
Air Blank	0.000	21:04:30

Preventative Maintenance Performed -- Timer Reset

EXHIBIT G-2 THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W. T. RYAN # 1100 AGENCY GOODYGAR POLICE DEFT
DATE 9-2-18 TIME 2033 HRS
INTOXILYZER SERIAL # 80-001858 LOCATION II N 1457H AVE GOODYGAR AZ 85338
1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution OR
Pour a standard alcohol concentration solutionAC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
 Intoxilyzer 8000 display reads "PUSH BUTTON TO START" Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
4. Air blank completed. 5. Calibration check completed. Test results 0. OO AC. 6. Air blank completed.
7. Remove printed record. Attach the record to the completed checklist.
SIGNATURE W. 7- Regan 1100
DPS Form Exh G-2 (Rev 05-01)

STANDARD CHANGE, NO ISSUES

Location: 11 N 145TH AVE Serial Number: 80-001858 Core Version: 8105.48

09/02/2018 20:33:39

Standard Lot#: 10818100A1 Last Changed By: W. RYAN #1100

DIG II DWAN HIIOO

QAS: W. RYAN #1100

GOODYEAR PD

Operator: W. RYAN #1100

GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	20:34:16
0.100 Cal Check	0.100	20:34:36
Air Blank	0.000	20:35:07

Preventative Maintenance Performed -- Timer Reset



7 Eastgate Dr. • P.O. Box 790 • Jacksonville, IL 62651-0790 217-245-2183 • Fax: 217-243-7634 • www.ilmoproducts.com

Certificate of Analysis

Certificate ID:

11089

Part #:

BAC105L100T

Cylinder Size:

Lot Number:

10818100A1

Expiration:

6/5/2020

0.100 BAC (For the calibration of instruments used to determine breath alcohol concentration)

Contents:

105 Liters @ 1000 psig 70°F (21°C)

Analytical

Reported

Accuracy

Analytical

Component:

Concentration:

(U, k=2):

Method:

Ethanol Nitrogen

260 ppm Balance

+/-0.002 BAC(G/210L) NDIR

[5.2 ppm]

Distributed by:

CMI Inc.

316 East Ninth Street Owensboro, KY 42303 Phone 866-835-0690 www.alcoholtest.com

*NIST Traceable Reference Material Cylinder No. CC274523 / Job No. 09160306 Certified 362.2 µmol/mol Ethanol in Nitrogen

Store in dry area, away from sources of heat, ignition and direct sunlight. Do not allow storage area to exceed 52 °C (125 °F).

ialty Gas Lab Tech



The calibration results within this certificate were obtained using equipment and standards capable of producing analytical results traceable to NIST, and apply only to the items contained on this certificate. ILMO Products Company makes no warranty or representation as to the suitability of the use of any information provided for any particular purpose. The information use is at the sole discretion and risk of the user. Liability shall be limited to established replacement cost of this material or service.