

INTOXILYZER 8000

Location: 11 N 145TH AVE

Serial Number: 80-000312

Core Version: 8105.48

01/01/2019

13:50:22

Standard Lot#: 10818100A1

Last Changed By: W. RYAN #1100

QAS: W. RYAN #1100

GOODYEAR PD

Operator: W. RYAN #1100

GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	13:50:55
0.100 Cal Check	0.099	13:51:16
Air Blank	0.000	13:51:46

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W. T. RYAN #1100 AGENCY GOODYEAR POLICE DEPT

DATE 1-1-2019 TIME 1350 HRS

INTOXILYZER SERIAL # 80-000312 LOCATION 11 N 145TH AVE, GOODYEAR AZ 85338

(✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
OR

Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$

- TS
TS
TS
TS
2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
 4. Air blank completed.
 5. Calibration check completed. Test results 0. 099 AC.
 6. Air blank completed.
 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W. T. Ryan 1100