

INTOXILYZER 8000

Location: 11 N 145TH AVE

Serial Number: 80-001858

Core Version: 8105.48

01/01/2019

13:50:49

-----  
Standard Lot#: 10818100A1

Last Changed By: W. RYAN #1100  
-----

QAS: w. ryan #1100

goodyear pd  
-----

Operator: w. ryan #1100

goodyear pd  
-----

Test	g/210L	Time
Air Blank	0.000	13:51:22
0.100 Cal Check	0.101	13:51:43
Air Blank	0.000	13:52:13

Preventative Maintenance  
Performed -- Timer Reset

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W.T. RYAN #1100 AGENCY GOODYEAR POLICE DEPT

DATE 1-1-2019 TIME 1350 HRS

INTOXILYZER SERIAL # 90-001858 LOCATION 11 N 145TH AVE, GOODYEAR AZ  
85338

1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100AC.

OR

Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$

2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
4. Air blank completed.
5. Calibration check completed. Test results 0. 101 AC.
6. Air blank completed.
7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W.T. Ryan 1100