

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST M. GILMAN 1144 AGENCY GOODYEAR PD
DATE 5/11/13 TIME 0220
INTOXILYZER SERIAL # 80-000312 LOCATION 111 S LITCHFIELD RD

- ☒ 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- ☒ 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- ☒ 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- ☒ 4. Air blank completed.
- ☒ 5. Calibration check completed. Test results 0. 101 AC.
- ☒ 6. Air blank completed.
- ☒ 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE LAG 1144

INTOXILYZER 8000

Location: 1111 S LICHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

05/11/2013

02:20:03

Standard Lot#: 13712100A2

Last Changed By: M. GUILBAULT #1144

QAS: M. GUILBAULT #1144

GOODYEAR PD

Operator: M. GUILBAULT #1144

GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	02:20:34
0.100 Cal Check	0.101	02:20:55
Air Blank	0.000	02:21:24

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST M. GUEVABANT 1144 AGENCY GOODYEAR PD
DATE 5/11/2013 TIME 0221
INTOXILYZER SERIAL # 80-000 312 LOCATION 1111 S LOTUSFIELD RD

(A) 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- (B) 1. Clock time check.
(P) 2. Date check.

OPERATIONAL TESTS

- (B) 1. Alcohol-free subject test result 0. 000 AC.
(A) 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
(D) 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
(X) 4. Standard Calibration Check standard 0. 100 AC. Result 0. 100 AC.

Instrument is operating properly and accurately. YES X NO

COMMENTS

SIGNATURE AG 1144

INTOXILYZER 8000
Location: 1111 S LICHFIELD RD
Serial Number: 80-000312
Core Version: 8105.48
05/11/2013

02:21:37

Standard Lot#: 13712100A2
Last Changed By: M. GUILBAULT #1144

QAS: M. GUILBAULT #1144
GOODYEAR PD

Operator: M. GUILBAULT #1144
GOODYEAR PD

Subject: TEST,TEST
DOB: 01/01/1990
Sex: M Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	02:22:26
Diagnostic Test	Pass	02:23:01
Air Blank	0.000	02:23:28
0.100 Cal Check	0.101	02:23:49
Air Blank	0.000	02:24:19
Subject Test	0.000	02:24:42
Air Blank	IPS*	02:24:48
Air Blank	RFI**	02:24:59

*Improper Sample

**RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: 1111 S LICHFIELD RD
Serial Number: 80-000312
Core Version: 8105.48
05/11/2013

02:25:03

Standard Lot#: 13712100A2
Last Changed By: M. GUILBAULT #1144

QAS: M. GUILBAULT #1144
GOODYEAR PD

Operator: M. GUILBAULT #1144
GOODYEAR PD

Subject: TEST,TEST

DOB: 01/01/1990

Sex: M Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	02:25:50
Diagnostic Test	Pass	02:26:25
Air Blank	0.000	02:26:53
Reference	ABT*	02:26:59
Air Blank	0.000	02:27:27

*Sequence Aborted

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: 1111 S LICHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

05/11/2013

02:31:51

Standard Lot#: 13712100A2

Last Changed By: M. GUILBAULT #1144

QAS: M. GUILBAULT #1144

GOODYEAR PD

Operator: M. GUILBAULT #1144

GOODYEAR PD

Subject: TEST,TEST

DOB: 01/01/1990

Sex: M

Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	02:32:38
Diagnostic Test	Pass	02:33:13
Air Blank	0.000	02:33:41
0.100 Cal Check	0.101	02:34:01
Air Blank	0.000	02:34:31
Subject Test	0.024*	02:37:39
Air Blank	0.000	02:38:11
Air Blank	0.000	02:38:38
Subject Test	XXX**	02:39:10
Air Blank	0.000	02:39:43

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: 1111 S LICHFIELD RD
Serial Number: 80-000312
Core Version: 8105.48
05/11/2013

02:27:34

Standard Lot#: 13712100A2
Last Changed By: M. GUILBAULT #1144

QAS: M. GUILBAULT #1144
GOODYEAR PD

Operator: M. GUILBAULT #1144
GOODYEAR PD

Subject: TEST,TEST
DOB: 01/01/1990
Sex: M Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	02:28:22
Diagnostic Test	Pass	02:28:57
Air Blank	0.000	02:29:24
0.100 Cal Check	0.100	02:29:45
Air Blank	0.000	02:30:15
Subject Test	0.026	02:30:33
Air Blank	0.000	02:31:07
Wait	ABT*	
Air Blank	0.000	02:31:46

*Sequence Aborted

Not a Successfully Completed Test Sequence

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST M. GLENN HUNT 1141 AGENCY GOODYEAR PD
DATE 5/11/13 TIME 0240
INTOXILYZER SERIAL # 80000312 LOCATION 1111 S LITCHFIELD RD

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (X) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0. 100 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE [Signature] 1141

INTOXILYZER 8000

Location: 1111 S LICHFIELD RD

Serial Number: 80-000312

Core Version: 8105.48

05/11/2013

02:40:21

Standard Lot#: 13712100A2

Last Changed By: M. GUILBAULT #1144

QAS: M. GUILBAULT #1144

GOODYEAR PD

Operator: M. GUILBAULT #1144

GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	02:40:50
0.100 Cal Check	0.100	02:41:11
Air Blank	0.000	02:41:41

Preventative Maintenance

Performed -- Timer Reset