

INTOXILYZER 8000  
Location: 11 N 145TH AVE  
Serial Number: 80-001858  
Core Version: 8105.48  
12/02/2019 10:38:46

-----  
Standard Lot#: 10818100A1  
Last Changed By: W. RYAN #1100  
-----

QAS: W. RYAN #1100  
GOODYEAR PD  
-----

Operator: W. RYAN #1100  
GOODYEAR PD  
-----

Test	g/210L	Time
Air Blank	0.000	10:39:18
0.100 Cal Check	0.100	10:39:39
Air Blank	0.000	10:40:08

Preventative Maintenance  
Performed -- Timer Reset

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W. T. RYAN #1100 AGENCY GOODYEAR POLICE DEPT

DATE 12-2-2019 TIME 1038 HRS

INTOXILYZER SERIAL # 90-001858 LOCATION LIN 145TH AVE, GOODYEAR AZ 85338

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0. 100 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W. T. Ryan #1100

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST K. MIYAZATO 1139 AGENCY GOODYEAR P.D.  
DATE 12/12/19 TIME 03:36  
INTOXILYZER SERIAL # 80-001858 LOCATION 11 N 145 TH AVE

1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
4. Air blank completed.
5. Calibration check completed. Test results 0. 099 AC.
6. Air blank completed.
7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE K. Miyazato 1139

INTOXILYZER 8000

Location: 11 N 145TH AVE

Serial Number: 80-001858

Core Version: 8105.48

12/12/2019

03:36:08

-----  
Standard Lot#: 10818100A1

Last Changed By: W. RYAN #1100  
-----

QAS: K. MIYAZATO #1139

GOODYEAR PD  
-----

Operator: K. MIYAZATO #1139

GOODYEAR PD  
-----

Test	g/210L	Time
Air Blank	0.000	03:36:55
0.100 Cal Check	0.099	03:37:16
Air Blank	0.000	03:37:46

Preventative Maintenance  
Performed -- Timer Reset