

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W.T. Ryan 1100 AGENCY GOODYEAR POLICE DEPT
DATE 3-25-14 TIME 1204
INTOXILYZER SERIAL # 90-001858 LOCATION 1111 S LITCHFIELD RD GOODYEAR AZ

- () 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- () 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- () 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- () 4. Air blank completed.
- () 5. Calibration check completed. Test results 0.097 AC.
- () 6. Air blank completed.
- () 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W.T. Ryan 1100

DPS Form Exh G-2 (Rev 05-01)

NO PROBLEMS OBSERVED

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

03/25/2014

12:04:28

Standard Lot#: 32012100A1

Last Changed By: W. WILL #974

QAS: W. RYAN #1100

GOODYEAR PD

Operator: W. RYAN #1100

GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	12:05:04
0.100 Cal Check	0.097	12:05:25
Air Blank	0.000	12:05:54

Preventative Maintenance
Performed -- Timer Reset