

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST M. GILMART AGENCY GOODYEAR RA
DATE 9/7/2013 TIME 0300
INTOXILYZER SERIAL # 80-001FS5 LOCATION 111 S LITCHFIELD RD.

- (/) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
OR
Pour a standard alcohol concentration solution 100 AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (/) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (/) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (/) 4. Air blank completed.
- (/) 5. Calibration check completed. Test results 0. 099 AC.
- (/) 6. Air blank completed.
- (/) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE WA 1144

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

09/07/2013

03:00:23

Standard Lot#: 34011100A1

Last Changed By: M. GUILBAULT #1144

QAS: M. GUILBAULT #1144

GOODYEAR PD

Operator: M. GUILBAULT #1144

GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	03:00:52
0.100 Cal Check	0.099	03:01:12
Air Blank	0.000	03:01:42

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST W.T. RYAN AGENCY GOODYEAR P.D.
DATE 9-27-13 TIME 1050
INTOXILYZER SERIAL # 80-001858 LOCATION 1111 S. LITCHFIELD RD.
GOODYEAR AZ

(✓) 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- (✓) 1. Clock time check.
(✓) 2. Date check.

OPERATIONAL TESTS

- (✓) 1. Alcohol-free subject test result 0. 0.00 AC.
(✓) 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
(✓) 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
(✓) 4. Standard Calibration Check standard 0. 100 AC. Result 0. 100 AC.

Instrument is operating properly and accurately. YES ☒ NO ☐

COMMENTS

SIGNATURE W.T. Ryan 1100

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

09/27/2013

10:50:40

Standard Lot#: 34011100A1

Last Changed By: M. GUILBAULT #1144

QAS: W. RYAN

#1100

GOODYEAR PD

Operator: W. RYAN

#1100

GOODYEAR PD

Subject: TEST,TEST

DOB: 10/15/1959

Sex: M

Weight: 180

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	10:52:43
Diagnostic Test	Pass	10:53:18
Air Blank	0.000	10:53:46
0.100 Cal Check	0.100	10:54:06
Air Blank	0.000	10:54:36
Subject Test	0.000	10:54:56
Air Blank	0.000	10:55:23
Wait	ABT*	
Air Blank	0.000	10:56:09

*Sequence Aborted

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

09/27/2013

10:46:37

Standard Lot#: 34011100A1

Last Changed By: M. GUILBAULT #1144

QAS: W. RYAN #1100

GOODYEAR PD

Operator: W. RYAN #1100

GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	10:47:40
0.100 Cal Check	0.100	10:48:00
Air Blank	0.000	10:48:30

Preventative Maintenance

Performed -- Timer Reset

INTOXILYZER 8000
Location: 1111 S LITCHFIELD RD
Serial Number: 80-001858
Core Version: 8105.48
09/27/2013 10:56:49

Standard Lot#: 34011100A1
Last Changed By: M. GUILBAULT #1144

QAS: W. RYAN #1100
GOODYEAR PD

Operator: W. RYAN #1100
GOODYEAR PD

Subject: TEST,TEST
DOB: 10/15/1959
Sex: M Weight: 180

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	IPS*	10:57:43
Air Blank	0.000	10:58:12

*Improper Sample

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

09/27/2013

11:00:29

Standard Lot#: 34011100A1

Last Changed By: M. GUILBAULT #1144

QAS: W. RYAN #1100

GOODYEAR PD

Operator: W. RYAN #1100

GOODYEAR PD

Subject: TEST,TEST

DOB: 10/15/1959

Sex: M

Weight: 180

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	RFI*	11:01:14
Air Blank	0.000	11:01:43

*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

09/27/2013

11:01:54

Standard Lot#: 34011100A1

Last Changed By: M. GUILBAULT #1144

QAS: W. RYAN #1100

GOODYEAR PD

Operator: W. RYAN #1100

GOODYEAR PD

Subject: TEST, TESI .

DOB: 10/15/1959

Sex: M

Weight: 180

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	11:03:00
Diagnostic Test	Pass	11:03:35
Air Blank	0.000	11:04:03
0.100 Cal Check	0.100	11:04:23
Air Blank	0.000	11:04:53
Subject Test	0.408*	11:08:01
Air Blank	0.000	11:08:36
Air Blank	0.000	11:09:03
Subject Test	XXX**	11:09:24
Air Blank	0.000	11:09:58

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: 1111 S LITCHFIELD RD

Serial Number: 80-001858

Core Version: 8105.48

09/27/2013

11:10:44

Standard Lot#: 34011100A1

Last Changed By: M. GUILBAULT #1144

QAS: W. RYAN #1100

GOODYEAR PD

Operator: W. RYAN #1100

GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	11:11:15
0.100 Cal Check	0.100	11:11:36
Air Blank	0.000	11:12:06

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W.T. Ryan 1100 AGENCY GOODYEAR P.D.
DATE 9-27-13 TIME 1034
INTOXILYZER SERIAL # 80-001858 LOCATION 1111 S. LITCHFIELD RD GOODYEAR AZ

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 10 AC.
OR

Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$

- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
(✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
(✓) 4. Air blank completed.
(✓) 5. Calibration check completed. Test results 0. 10 AC.
(✓) 6. Air blank completed.
(✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE W.T. Ryan 1100