

Intoxilyzer - Alcohol Analyzer

Model 9000

SN: 90-003795

Test Date: 01/17/2023

Test Time: 20:28

Location: 11 N 145TH AVENUE

Software Version: 9439.01.00

Standard Lot #: 28021100A1

Standard Value: 0.100

Expiration Date: 12/05/2023

Bottle #: 001

Last Changed By: MIYAZATO, KORY

Permit #: 30215

Operator: MIYAZATO, KORY

Permit #: 30215

Agency: GOODYEAR PD

| Test | g/210L | Time |
|-----------------|--------|----------|
| Air Blank | 0.000 | 20:28:57 |
| Calibration Chk | 0.099 | 20:29:18 |
| Air Blank | 0.000 | 20:29:58 |

No RFI Detected

Intoxilyzer - Alcohol Analyzer

Model 9000

SN 90-003795

Version - 9439.01.00

Test Date -1/17/2023 Test Time -20:25

Location - 11 N 145TH AVENUE

| <u>Test</u> | <u>g/210L</u> | <u>Time</u> |
|-----------------|---------------|-------------|
| Air Blank | 0.000 | 20:25:56 |
| Diagnostic Test | PASS | 20:26:31 |

Extended Diag Info

Analytical Checksum PASS
Voltage/Current PASS
Memory PASS
Real Time Clock PASS
Temp Regulation PASS
ADC PASS
Analytical Status PASS
Version Status PASS
ITP PASS

EXHIBIT I-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
INTOXILYZER MODEL 9000

PERIODIC MAINTENANCE AND STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST K Miyazawa 1139 AGENCY Goodyear PD
DATE 1/31/2023 TIME _____
INTOXILYZER SERIAL # 90-003795

1. Ensure that gas tank is attached and contains a standard alcohol concentration 100 AC

DIAGNOSTIC TESTS

1. Clock time check
 2. Date check

OPERATIONAL TESTS

1. Deficient Subject Test (Proper Sample Recognition)
Deficient Sample printed
2. Alcohol-free Subject Test (Proper Sample Recognition):
0. 000 AC
3. Mouth Alcohol Subject Test (Proper Sample Recognition):
Invalid Sample – Begin new deprivation period printed
4. Radio Frequency Interference Test (Error Recognition):
RFI Detect printed
5. Standard Calibration Check:
0. 098 AC
6. Air Blanks Completed
7. Timer Reset

Not a Successfully Completed Test Sequence will be printed

Instrument is operating properly and accurately. YES NO _____

COMMENTS:

SIGNATURE K Miyazawa

ARIZONA FORENSIC BREATH ALCOHOL ANALYTICAL REPORT

11 N 145TH AVENUE

INSTRUMENT INFORMATION

Analytical Instrument: Intoxilyzer 9000
Serial Number: 90-003795
Software Version: 9439.01.00
Analytical Report Number: 37950131230141

QAS: MIYAZATO, KORY
QAS Permit #: 30215
Agency: GOODYEAR PD
Last 31-Day Check: 01/31/2023
Last Annual Maintenance: 08/03/2022

SUBJECT INFORMATION

Name: 31-Day Check
Test Date: 01/31/2023
Driver's License #:
Gender:
Date of Birth:
Age:

Weight:
State of Issue:
Driver's License Expiration:
Deprivation Start Time: 00:45
15 - Minute Deprivation: Yes

OPERATOR INFORMATION

Name: MIYAZATO, KORY
Agency: GOODYEAR PD

Permit #: 30215

STANDARD INFORMATION

Standard Value: 0.100
Standard Lot #: 28021100A1
Expiration Date: 12/05/2023
Bottle #: 001
Last Changed By: MIYAZATO, KORY

Permit #: 30215

| Test | g/210L | Time |
|-----------------|--------|----------|
| Air Blank | 0.000 | 01:11:16 |
| Diagnostic Test | PASS | 01:11:52 |
| Air Blank | 0.000 | 01:12:28 |
| Calibration Chk | 0.099 | 01:12:50 |
| Air Blank | 0.000 | 01:13:29 |
| Subject Test 1 | NSG* | 01:16:43 |
| Air Blank | 0.000 | 01:17:24 |
| Air Blank | 0.000 | 01:18:04 |
| Subject Test 2 | 0.000 | 01:18:22 |
| Air Blank | 0.000 | 01:19:03 |
| Wait | | 01:23:07 |
| Air Blank | 0.000 | 01:23:44 |
| Subject Test 3 | INV** | 01:24:02 |
| Air Blank | RFI*** | 01:24:20 |

RESULTS

EXCEPTION MESSAGES

*No Sample Given
**Invalid Sample - Begin new deprivation period
***RFI Detect

* No Sample Given
** Invalid Sample - Begin new deprivation period
*** RFI Detect

OPERATOR COMMENTS

Not a Successfully Completed Test Sequence

All air blank results must be 0.000.
Consecutive subject test results must not differ by more than 0.020 g/210L.
Standard check results must be $\pm 10\%$.

Intoxilyzer - Alcohol Analyzer
Model 9000

SN: 90-003795

Test Date: 01/31/2023

Test Time: 01:24

Location: 11 N 145TH AVENUE

Software Version: 9439.01.00

Standard Lot #: 28021100A1

Standard Value: 0.100

Expiration Date: 12/05/2023

Bottle #: 001

Last Changed By: MIYAZATO, KORY

Permit #: 30215

Operator: MIYAZATO, KORY

Permit #: 30215

Agency: GOODYEAR PD

| <u>Test</u> | <u>g/210L</u> | <u>Time</u> |
|-----------------|---------------|-------------|
| Air Blank | 0.000 | 01:25:14 |
| Calibration Chk | 0.098 | 01:25:36 |
| Air Blank | 0.000 | 01:26:16 |

No RFI Detected

ARIZONA FORENSIC BREATH ALCOHOL ANALYTICAL REPORT

11 N 145TH AVENUE

INSTRUMENT INFORMATION

Analytical Instrument: Intoxilyzer 9000
Serial Number: 90-003795
Software Version: 9439.01.00
Analytical Report Number: 37950131230140

QAS: MIYAZATO, KORY
QAS Permit #: 30215
Agency: GOODYEAR PD
Last 31-Day Check: 12/30/2022
Last Annual Maintenance: 08/03/2022

SUBJECT INFORMATION

Name: 31-Day Check
Test Date: 01/31/2023
Driver's License #:
Gender:
Date of Birth:
Age:

Weight:
State of Issue:
Driver's License Expiration:
Deprivation Start Time: 00:45
15 - Minute Deprivation: Yes

OPERATOR INFORMATION

Name: MIYAZATO, KORY
Agency: GOODYEAR PD

Permit #: 30215

STANDARD INFORMATION

| <u>Test</u> | <u>g/210L</u> | <u>Time</u> |
|-----------------|---------------|-------------|
| Air Blank | 0.000 | 01:09:26 |
| Diagnostic Test | DIA* | 01:09:32 |
| Air Blank | 0.000 | 01:10:09 |

Standard Value: 0.100
Standard Lot #: 28021100A1
Expiration Date: 12/05/2023
Bottle #: 001
Last Changed By: MIYAZATO, KORY

*00004000000
IRPCM Status Error

Permit #: 30215

RESULTS

EXCEPTION MESSAGES

* Diagnostic Fail

OPERATOR COMMENTS

No RFI Detected

Not a Successfully Completed Test Sequence

All air blank results must be 0.000.

*Consecutive subject test results must not differ by more than 0.020 g/210L.
Standard check results must be ±10%.*