

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST R Miyazaki 1139 AGENCY GOODYEAR PD
DATE 6/30/23 TIME _____
INTOXILYZER SERIAL # 80-000312 LOCATION 11 N 145TH AVE

() 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- () 1. Clock time check.
() 2. Date check.

OPERATIONAL TESTS

- () 1. Alcohol-free subject test result 0. 000 AC.
() 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
() 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
() 4. Standard Calibration Check standard 0. 100 AC. Result 0. 098 AC.

Instrument is operating properly and accurately. YES NO _____

COMMENTS

SIGNATURE [Signature] 1139

INTOXILYZER 8000

Location: 11 N 145TH AVE

Serial Number: 80-000312

Core Version: 8105.48

06/30/2023

04:37:18

Standard Lot#: 28021100A1

Last Changed By: K. MIYAZATO #1139

QAS: K. MIYAZATO #1139

GOODYEAR PD

Operator: K. MIYAZATO #1139

GOODYEAR PD

Subject: SQAP,TEST

DOB: 04/02/1973

Sex: M Weight: 199

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	04:38:20
Diagnostic Test	Pass	04:38:55
Air Blank	0.000	04:39:23
0.100 Cal Check	0.099	04:39:43
Air Blank	0.000	04:40:14
Subject Test	0.000	04:40:30
Air Blank	ABT*	04:40:37
Air Blank	0.000	04:41:05

*Sequence Aborted

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: 11 N 145TH AVE
Serial Number: 80-000312
Core Version: 8105.48
06/30/2023 04:41:14

Standard Lot#: 28021100A1
Last Changed By: K. MIYAZATO #1139

QAS: K. MIYAZATO #1139
GOODYEAR PD

Operator: K. MIYAZATO #1139
GOODYEAR PD

Subject: SQAP,TEST
DOB: 04/02/1973
Sex: M Weight: 199

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	IPS*	04:41:58
Air Blank	0.000	04:42:26

*Improper Sample

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: 11 N 145TH AVE
Serial Number: 80-000312
Core Version: 8105.48
06/30/2023 04:42:29

Standard Lot#: 28021100A1
Last Changed By: K. MIYAZATO #1139

QAS: K. MIYAZATO #1139
GOODYEAR PD

Operator: K. MIYAZATO #1139
GOODYEAR PD

Subject: SQAP, TEST
DOB: 04/02/1973
Sex: M Weight: 199

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	RFI*	04:43:03
Air Blank	RFI*	04:43:23

*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: 11 N 145TH AVE
Serial Number: 80-000312
Core Version: 8105.48
06/30/2023 04:43:27

Standard Lot#: 28021100A1
Last Changed By: K. MIYAZATO #1139

QAS: K. MIYAZATO #1139
GOODYEAR PD

Operator: K. MIYAZATO #1139
GOODYEAR PD

Subject: SQAP,TEST
DOB: 04/02/1973
Sex: M Weight: 199

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	04:44:17
Diagnostic Test	Pass	04:44:52
Air Blank	0.000	04:45:20
0.100 Cal Check	0.099	04:45:41
Air Blank	0.000	04:46:11
Subject Test	0.065*	04:49:18
Air Blank	0.000	04:49:50
Air Blank	0.000	04:50:18
Subject Test	0.106	04:50:36
Air Blank	IPS**	04:50:42
Air Blank	0.000	04:51:12

*Deficient Sample

**Improper Sample

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: 11 N 145TH AVE
Serial Number: 80-000312
Core Version: 8105.48
06/30/2023 04:33:52

Standard Lot#: 28021100A1
Last Changed By: K. MIYAZATO #1139

QAS: K. MIYAZATO #1139
GOODYEAR PD

Operator: K. MIYAZATO #1139
GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	04:34:23
0.100 Cal Check	0.099	04:34:44
Air Blank	0.000	04:35:14

Preventative Maintenance
Performed -- Timer Reset

INTOXILYZER 8000
Location: 11 N 145TH AVE
Serial Number: 80-000312
Core Version: 8105.48
06/30/2023 04:52:10

Standard Lot#: 28021100A1
Last Changed By: K. MIYAZATO #1139

QAS: K. MIYAZATO #1139
GOODYEAR PD

Operator: K. MIYAZATO #1139
GOODYEAR PD

Test g/210L Time

Air Blank 0.000 04:52:40
0.100 Cal Check 0.098 04:53:01
Air Blank 0.000 04:53:31

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST K Miyazato 1139 AGENCY Goodyear PD
DATE 6/30/23 TIME 0452
INTOXILYZER SERIAL # 80-000312 LOCATION W 145TH AVE

- () 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- () 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- () 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- () 4. Air blank completed.
- () 5. Calibration check completed. Test results 0. 098 AC.
- () 6. Air blank completed.
- () 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE K Miyazato 1139